

HITACHI

•F• หม้อหุงข้าวระบบฟิชชี่ คอนโทรล

คู่มือการใช้งานหม้อหุงข้าวไฟฟ้า ฮิตาชิ

รุ่น : RZ-D10WF / RZ-D18WF

เครื่องใช้ไฟฟ้าภายในบ้าน



ข้าวอบสับปะรด



สตอร์ว์เบอร์รีเค้ก

ข้อมูลการใช้งาน

ข้อปฏิบัติเพื่อความปลอดภัย.....	2
ส่วนประกอบของหม้อหุงข้าว	4

ก่อนเริ่มหุงข้าว

คำแนะนำและเคล็ดลับในการหุงข้าวให้อร่อย	5
การเตรียมอาหารหุง	6

การใช้งาน

วิธีหุงข้าว (ข้าวขาว/ข้าวหอมมะลิ/ข้าวญี่ปุ่น/ข้าวกล้อง/ข้าวอบสับปะรด	
ข้าวต้ม/เจ็กข้าวเหนียว/ข้าวผัด)	7
การใช้เมมอคตโนมัติ (การทำอาหาร 40 เม็ด)	8
การยุ่นข้าวที่พุงกุ้งเผา	9
วิธีการหุงพร้อมนึ่ง	10
วิธีการอบเค้ก	11
วิธีการตัน	12
วิธีการตั้งเวลาส่วนหัว	13
วิธีการนึ่ง	14
การทำความสะอาด	15
การเวิเคราะห์ปัญหาที่เกิดขึ้น	16

คู่มือการทำอาหาร โปรแกรมหุงพร้อมนึ่ง

ถุงน้ำเชื่อม	17
ไก่ชิ่งไช	17
บูนึงแบบผัดพิริก	18
ปลาร้าเผา	18
เต้าหู้น้ำแดง	19
ก้าด ก้าด	19
ไข่ตุ๋นถุง	20
ปลาอ่อนต้มเต้ม	20
ผัดเขียวหวานไก่	21
ผัดผักรามมีดคร	21

ข้อมูลจำเพาะ

ข้อมูลจำเพาะ	22
--------------------	----

- ขอบคุณที่เลือกซื้อหม้อหุงข้าวไฟฟ้าฮิตาชิ
- โปรดอ่านคู่มือการใช้งานนี้ก่อนใช้งาน เพื่อการใช้ผลิตภัณฑ์นี้อย่างถูกต้อง
เมื่ออ่านแล้ว โปรดเก็บไว้ในที่ที่สะดวกต่อการนำกลับมาอ่านซ้ำในอนาคต

ข้อปฏิบัติเพื่อความปลอดภัย

ผลิตภัณฑ์นี้สำหรับใช้ภายในครัวเรือนเท่านั้น ห้ามใช้เพื่อวัตถุประสงค์ในเชิงอุตสาหกรรม

 คำเตือน	แสดงถึงอันตรายที่อาจทำให้เกิดอันตรายถึงชีวิต หรือการบาดเจ็บ
 ข้อควรระวัง	แสดงถึงอันตรายที่อาจทำให้เกิดความเสียหาย เล็กน้อยหรือบาดเจ็บไม่รุนแรง กับเครื่องใช้ไฟฟ้า หรือหัวพัดลม

 คำเตือน	
มีความเสี่ยงที่จะเกิดแพลงเมจิกซึ่งก่อให้เกิดภัยในหม้อหุงข้าว หากเปิดไฟโดยทันที เพื่อให้แน่ใจว่าปิดไฟสินิ โปรดกดตรงกลางด้านหน้าของไฟ จนกว่าจะได้ยินเสียง “คลิก” ไม่ควรใช้หม้อหุงข้าวที่เพื่อจุดประஸ์ค์อื่นๆ นอกเสียจากการหุงข้าว และปูนอาหารตามที่ระบุไว้ในคู่มือการใช้งานและห้ามทำการทำความสะอาด	 ห้ามถอนหัวปลั๊กไฟ ของผลิตภัณฑ์นี้ การใช้บริการต่างๆ อาทิ การร่ออุ่น ควรใช้บริการจากทางบริษัทฯ ผู้ให้บริการที่ได้รับการแต่งตั้งจากทางบริษัทฯ เพราะอาจเกิดอันตรายจากไฟลิงใหม่ ไฟครุ หรือผิวนั้นพุพองได้ เมื่อต้องการใช้บริการ ให้ติดต่อร้านค้าที่คุณซื้อสินค้า หรือ แผนกบริการลูกค้าของบริษัทฯ ด้วย  ห้ามยกขึ้นสูบ
อย่าพยายามใช้สายไฟ เชิ่ม ลวด หรือวัสดุโลหะใดๆ กับผลิตภัณฑ์นี้ เพราะอาจเป็นสาเหตุให้เกิดไฟครุ หรือเป็นอันตราย เนื่องจากหม้อหุงข้าวทำงานผิดปกติ	 เครื่องใช้ไฟฟ้านี้ใช้กับปลั๊กไฟ 5A ขึ้นไป และควรเสียบแยก เพียงอุปกรณ์เดียว หากเสียบปลั๊กไว้กับอุปกรณ์อื่น อาจทำให้เกิดความร้อนสูงสุดถึงปีก และเกิดไฟลิงใหม่เป็นอันตรายได้
เก็บหม้อหุงข้าวให้พ้นมือเด็กเสมอ เพราะอาจเกิดไฟครุ หรือการมาดเจ็บอื่นๆ ได้	 ดูแลบล็อกไฟให้สะอาด มีฉนั้นอาจเป็นสาเหตุของเพลิงไหม้ได้
อย่าใช้งาน เมื่อพับร้าสายไฟหรือปลั๊กชาร์จ เพราะอาจทำให้เกิดไฟครุ ไฟฟ้าลัดวงจร หรือเกิดเพลิงไหม้ได้	 ตรวจสอบว่าปลั๊กเสียบแน่นหนักแล้วเสียบดีหรือไม่ มีฉนั้นอาจเป็นสาเหตุให้เกิดไฟครุ ไฟฟ้าลัดวงจร เกิดควัน หรือเพลิงไหม้ได้
อย่าทำให้สายไฟเกิดความเสียหาย ไม่ว่าในกรณีใดๆ และไม่ควรวางสายไว้ติดกับแหล่งกำเนิดความร้อน สายที่ชำรุดอาจทำให้เกิดไฟครุ หรือเพลิงไหม้ได้	 เสียบปลั๊กเข้ากับเตาเดี่ยวเสียบที่บีบไฟฟ้ากระแสสลับและวัสดุร้อนด้าน 220 โวลต์เท่านั้น มีฉนั้นอาจทำให้เกิดไฟครุ หรือเพลิงไหม้ได้
ห้ามเปิดไฟห้องในขณะที่เครื่องกำลังหุงข้าวอยู่ เพราะผิวนั้นอาจเกิดแพลงไฟฟ้าพุพองจากไอน้ำได้	 หลีกเลี่ยงการนำด้าวหม้อหุงข้าวลงไปแช่ในน้ำ หรือเทน้ำลงใน ส่วนต่างๆ ของด้าวเครื่อง เพราะอาจทำให้เกิดไฟครุ ไฟฟ้าลัดวงจร เป็นอันตรายได้
เครื่องใช้ไฟฟ้านี้ไม่สามารถใช้กับบุคคล (รวมทั้งเด็กเล็ก) ที่มีศักยภาพร่างกาย จิตใจ และระบบประสาทไม่สมบูรณ์ หรือผู้ที่ขาดความรู้และประสบการณ์ ถ้าไม่ใช่นั้นต้องอยู่ใน การดูแลหรือได้รับคำแนะนำในการใช้งานเครื่องใช้ไฟฟ้านี้ จากผู้ที่สามารถรับผิดชอบต่อความปลอดภัยของบุคคลที่มี ความบกพร่องดังกล่าวได้ ต้องให้แน่ใจว่ามีผู้ดูแล เมื่อไม่ได้เก็บเล่นเครื่องใช้ไฟฟ้า	 หลีกเลี่ยงการเสียบหรือดึงปลั๊กในขณะที่มือเปียก เพราะอาจทำให้ไฟครุถังแก้ววิเศษได้
	 ไม่ควรใช้ใน ขณะมือเปียก
	 ห้ามจับช่องระบายไอน้ำขณะใช้งาน
	เพราะอาจทำให้ด้าวไหม้  เก็บหม้อหุงข้าวให้พ้นมือเด็ก

ສັນລັກໝົດ



ສັນລັກໝົດນີ້ແສດງດຶງ “ຂ້ອທ້າມ” ດໍາວິນາຍ
ອ່ານຕາຍຫວູ້ຄໍາເຕີດໃໝ່ (ວິນາຍ)
ອ່ານຕາຍຫວູ້ຄໍາເຕີດໃໝ່ (ວິນາຍ)



ສັນລັກໝົດນີ້ແສດງດຶງ “ຂ້ອທ້າມ” ດໍາວິນາຍ
ອ່ານຕັ້ງຈົນຢູ່ກາຍໃນຫວູ້ຄໍາເຕີດຈາກສັນລັກໝົດນີ້



ສັນລັກໝົດນີ້ແສດງດຶງ “ຂ້ອນັບັບ” ດໍາວິນາຍ
ອ່ານຕັ້ງຈົນຢູ່ກາຍໃນຫວູ້ຄໍາເຕີດຈາກສັນລັກໝົດນີ້

ຮູ້ປະການກໍານົດການໃໝ່ງງານ

ຂ້ອຄວະຮະວັງ


ທ້າມໃຊ້ໄກລັນ້າຫວູ້ໄພ ເພະາຈາກທໍາໃຫ້ເກີດໄຟຟູດຫວູ້ໄພໄຟຟັ້ງໄດ້		ດອດລັກກອດຈາກເດົາເສີບເນື້ອໄຟໄດ້ໃຊ້ງານ ມີມະນັ້ນຈາກທໍາໃຫ້ໄພແໜ້ນຫັນພຸພອງ ທີ່ກ່ຽວກັບມາດເຈັບຈາກເກີດຫຸ້ນ ໄດ້ຈາກໄຟຟູດຫວູ້ໄພໄຟຟັ້ງວັນເນື່ອມາຈາກການເລື່ອມສຳພາບຂອງຈຸນວນ	
ທ້າມວາງໝອຫຸແງຂ້າວມັນຜົວທີ່ໄມ່ເຮັດວຽກ ທ່ານນັ້ນຜົວທີ່ທ່າງຈາກ ວັດຖຸທີ່ຕິດໄຟ່ງາຍ ເຂົ້າ ພຣມ ທີ່ກ່ຽວກັບໂຕະ ເພະາຈາກເປັນສາເຫຼຸຂອງເພັ່ນໄໝໄດ້		ຂະໜະດອດລັກຈົບທີ່ດັບປັກ ໄຟໄວ້ຈົບທີ່ສາຍໄຟ ທາກໄນ່ປົງປັບຕົມຈາກທໍາໃຫ້ເກີດການນັດເຈັບ ພົບໄຟຟັ້ງໄດ້	
ໃຊ້ໜ້ານີ້ໃໝ່ນຳພັກກັນດັບໜ້ານີ້ຫຸແງຂ້າວເທົ່ານັ້ນ ມີມະນັ້ນໜ້າຈາກເກີດການວັນສູງເກີນ ທີ່ກ່ຽວກັບການເປັນປົກຕົວໄດ້		ຈັບທີ່ຫັບປັກຂະໜະດອດສາຍໄຟ ທາກດີ່ງທີ່ຄ້າຍອາກທໍາໃຫ້ເກີດອັນຕາຍໄດ້	
ອ່າຍ້ສັນພັກປຸ່ມເປີດຝາະນະເຄລື່ອນຍ້າຍໜ້າຫຸແງຂ້າວ ຫາກຝາ່ມ້າວັບປິດ ອາຈທໍາໃຫ້ເກີດອັນຕາຍຫວູ້ຄໍາເຕີດໄຟຟັ້ງໄດ້		ຄວາດຫຼາດທີ່ກ່ຽວກັບສະຄັດໜ້າຫຸແງຂ້າວ ລັງຈາກທີ່ຫຸແງຂ້າວເຍັນ ລົງແລ້ວ ການສັນພັກໜ້າສົວນີ້ທີ່ຍັງຮັນຈາກທໍາໃຫ້ຜົວໄໝໄດ້	
ອ່າຍ້ວາງໝອຫຸແງຂ້າວຕິດພັນນັ້ນຫວູ້ຄໍາເຕີດເຮືອນອື່ນໆ ອ່າຍ້ໄສ ໜ້າຫຸແງຂ້າວໃນຫຼູ່ກາຍໃນຄວ້າ ເພະາຈາກເກີດການສະສົມຂອງໄອນ້ ໄອນ້ຫວູ້ຄໍາເຕີດວັນອາຈທໍາໃຫ້ພັນ ພົບໄຟຟັ້ງເຮືອນລື້ອືບ ຫວູ້ຄໍາເຕີດໄຟຟັ້ງໄດ້		ຄວາມສະຄັດເຄື່ອງໃຫ້ໄຟຟັ້ງທຸກຄັ້ງທຸກການໃຊ້ງານ ອ່າຍ້ວາງໜ້າຫຸແງຂ້າວໃຫ້ມີມະນັ້ນຫຸແງຂ້າວ ຫວູ້ຄໍາເຕີດໄຟຟັ້ງໄດ້	

ຂ້ອຄວະປົງບົດ


• ອ່າຍ້ວາງຜ້າຫົ່ນນັ້ນໜ້າຫຸແງຂ້າວ ເພະາຈາກທໍາໃຫ້ໜ້າສືບສືບ ເລີ່ມວູ່ປົງປັບຫຸ້ນ ທີ່ກ່ຽວກັບການປົກຕົວໄດ້	• ອ່າຍ້ໃຫ້ມີລົງແປລກປອມໄດ້ ທີ່ຂອບດ້ານລ້າງຂອງໜ້າໃນ ຫວູ້ຄໍາເຕີດ ການປົງປັບຕົມຈາກທໍາໃຫ້ໜ້າຫຸແງຂ້າວຂັ້ນຂອງ ທາກໄນ່ປົງປັບຕົມຈາກທໍາໃຫ້ໜ້າຫຸແງຂ້າວຂັ້ນຂອງ ພົບໄຟຟັ້ງໄດ້
• ອ່າຍ້ກູ້ຫຸ້ນຫວູ້ຄໍາເຕີດເຄລື່ອນຍ້າຍໜ້າຫຸແງຂ້າວໃນຂອບທີ່ກ່າລັງຫຸ້ນ ໄອນ້ອາຈທໍາໃຫ້ຜົວໄໝໄດ້	
• ພົກເລີ່ມການສັນພັກກັບແສງຫວູ້ຄໍາເຕີດໂຄຍຕຽງ ເພະາຈາກທໍາໃຫ້ສົວນັ້ນຫວູ້ຄໍາເຕີດແລະເລີ່ມວູ່ປົງປັບຫຸ້ນ	• ອ່າຍ້ວາງດັບໜ້າໃນນັ້ນເປົາໄຟຟັ້ງ ຫວູ້ຄໍາເຕີດໄຟຟັ້ງໄດ້ ເພະາຈາກທໍາໃຫ້ສັງເກົາໄຟຟັ້ງໄດ້

ส่วนประกอบของหม้อหุงข้าว

ส่วนประกอบของหม้อหุงข้าว



ปุ่มควบคุม



ข้อสังเกต ปุ่มหุงข้าว/อุ่นข้าว [Cook/Reheat] จะมีลักษณะเป็นปุ่มมุนรูปทรง ○ สำหรับผู้ใช้การทางสายตา

คำแนะนำและเคล็ดลับในการหุงข้าวให้อร่อย

ข้อแนะนำในการใช้งาน

วิธีหุงข้าวให้อร่อย

การต้มข้าวให้ถูกวิธี

- ใช้ถ้วยตวงที่ได้มาพร้อมหม้อหุงข้าวในการต้มข้าว
- บางครั้งการต้มข้าวด้วยถ้วยตวงอาจต้องได้ปริมาณแตกต่างกัน ขึ้นอยู่กับถ้วยตวงแต่ละใบที่ได้มา

ข้าวขาวอย่างรวดเร็วและสะอาดเพียงพอ

- ข้าวจะดูดซับน้ำเร็วอย่างรวดเร็ว เท่าน้ำข้าวแรกทันที เพื่อให้ข้าวมีกลิ่นเหมือนรำข้าว
- จากนั้น ให้ข้าวซ้ำซ้ำหน้าสะอาด

พรวนข้าวหลังการหุง

- พรวนข้าวในหม้อให้ทันทีโดยยกด้วย จะช่วยให้น้ำส่วนเกินระเหยได้ดียิ่งขึ้น และทำให้ข้าวมีรสชาติดีอ่อนโยน
- ควรพรวนข้าวแม้ว่าคุณต้องการจะให้ข้าวยังคงถูกและอร่อย

อุ่นข้าวให้ร้อนเพื่อให้ข้าวมีรสชาติอร่อย

เพื่ออุ่นข้าวให้ร้อนและมีรสชาติ โปรดหลีกเลี่ยงการกระทำต่อไปนี้

- อุ่นข้าวที่หุงสุกแล้วนานกว่า 12 ชั่วโมง
- อุ่นข้าวที่เย็นแล้วให้ร้อนอีกร้อนหรือเดินข้าวลงไป
- อุ่นข้าวโดยย่างไฟไวในหม้อหุงข้าว
- อุ่นข้าวประเภทน้ำที่ไม่ใช่ข้าวสวย (เช่น ข้าวเหนียว ข้าวกล้อง ข้าวต้ม โจ๊ก ข้าวผัด)
- อุ่นข้าวที่หุงสุกแล้วโดยถางฟองไม่ละเอียด

ข้าวเหลือกันหม้อ

- เมื่อเมล็ดข้าวเหลือเพียงเล็กน้อย ให้ตักรวมกันไว้ตรงกลางหม้อใน (เพื่อบีบองกันไม่ให้ข้าวแห้งหรือแตก)

ข้อควรจำ

- หากคุณต้องการหุงข้าวไว้ในหม้อนา กิน 12 ชั่วโมง รวมทั้งข้าวประทัดอื่นๆ คุณสามารถหุงข้าวตามปกติ ของข้าวให้ยังคงความอ่อนโยนได้โดยใช้พลาสติกห่อ แล้วนำไปอุ่นในเตาไฟฟ้าได้ตลอดเวลา
- การพรวนข้าวเป็นครั้งคราวในขณะที่อุ่นข้าวจะช่วยให้ข้าวบังคับมีรสชาติอร่อย
- เมื่อให้อุ่นปุ่มน้ำประทัดอ่อนหุงข้าว ก่อนนำข้าวมาอุ่นในหม้อหุงข้าว ให้กดปุ่มอุ่นอ่อน เพื่ออุ่นให้หม้อในร้อน

เรื่องน่ารู้เกี่ยวกับข้าว

บริเวณน้ำและข้าวประเภทต่างๆ

- เดิมที่น้ำให้เหมาะสมสมกับชนิดของข้าวหรือตามความต้องการ

ชนิดของข้าว	ระดับน้ำ	เมนู
ข้าวหอมมะลิ	ตามระดับของข้าวหอมมะลิ	ข้าวหอมมะลิ
ข้าวผัด	ตามระดับของข้าวผัด	ข้าวผัด
ข้าวเหนียว	ตามระดับของข้าวเหนียว	ข้าวเหนียว
ข้าวผัด	ตามระดับของข้าวผัด	ข้าวผัด

ทำไมข้าวที่หุงแล้วเนื้อ?

การหุงข้าวทำให้ข้าวมีรสชาติและกลิ่นหอม หากคุณไม่ต้องการให้ข้าวไหม้ ควรหุงข้าวให้สะอาด เพื่อไม่ให้มีริ้วข้าวเหลืออยู่ ข้าวขาวและข้าวประเภทอื่นๆ (ที่ไม่ใช่ข้าวหอมมะลิ) มีแนวโน้มที่จะหุงแล้วให้มีกลิ่นเหม็นมากกว่าปกติ

ข้าวผัด

ชนิดของข้าว	อัตราการผสม	ระดับน้ำ	เมนู	ปริมาณการหุงสูงสุด		
				1.0 ลิตร	1.8 ลิตร	
ข้าวหอมมะลิ	: ข้าวเหนียว : ข้าวนมปู : ข้าวกล้องหอมมะลิ	3 : 1 3 : 1 1 : 1	ข้าวหอมมะลิ ข้าวกล้อง ข้าวกล้อง	ข้าวผัด ข้าวผัด ข้าวผัด	5 ถ้วย 4 ถ้วย 4 ถ้วย	10 ถ้วย 7 ถ้วย 7 ถ้วย
ข้าวกล้องหอมมะลิ	: ข้าวเหนียว : ข้าวตากแห้ง	3 : 1 1 : 1	ข้าวหอมมะลิ ข้าวกล้อง	ข้าวผัด ข้าวผัด	5 ถ้วย 4 ถ้วย	10 ถ้วย 7 ถ้วย

ตัวอย่าง

อัตราการผสม ข้าวหอมมะลิ : ข้าวเหนียว อัตราการผสม 3 : 1 หมายถึง ข้าวหอมมะลิ 3 ถ้วยตวง : ข้าวเหนียว 1 ถ้วยตวง

หมายเหตุ การหุงข้าวผัดจะหุงไว้ ข้าวหอมมะลิ : ข้าวกล้อง และข้าวกล้อง : ข้าวตากแห้ง เมื่อหุงเสร็จควรอุ่นต่ออีกประมาณ 10-15 นาที ข้าวจะรูม น้ำรันประทานยิ่งขึ้น

การเตรียมการหุง

ตัวอปี๊ง : เมื่อหุงข้าวด้วยเมนูข้าวลายจำนวน 3 ถ้วย

1

ดวงข้าวด้วยถ้วยดวงที่ได้มาร่วมหม้อหุงข้าว

- ข้าว 1 ถ้วยตวง มีปริมาตรประมาณ 180 มล.



2

ข้าวข้าว ① ใส่น้ำให้มากพอแล้วข้าวข้าว จากนั้นให้เทเน้าทึ้งทันที

② ทำข้าชั้นตอน “ข้าว → เทเน้า” จนน้ำสระออก

หมายเหตุ



- ใช้ภาชนะที่แยกต่างหากในการข้าวข้าว ไม่ควรข้าวข้าวด้วยหม้อใน
- ข้าวข้าวให้สะอาด
(มีฉนั้นข้าวอาจไหม้หรือมีกลิ่นรำข้าว)
- ใช้มือในการข้าวข้าว อย่าใช้ไม้คัน
- เมื่อทำข้าวข้าวแบบต่างๆ อย่าใส่ข้าวจนถึงระดับสูงสุด
(4 ถ้วยสำหรับหม้อขนาด 1.0 ลิตร และ 7 ถ้วยสำหรับหม้อขนาด 1.8 ลิตร)

สาเหตุของการเกิดน้ำล้น (Overflow)

- สาเหตุของการเกิดน้ำล้นในขณะที่หุงข้าวอาจเกิดจากการข้าวข้าวไม่สะอาดเพียงพอหรือการเติมน้ำมากเกินไป

3

เติมน้ำให้ถึงระดับที่เหมาะสมตามประเภทของข้าวที่เลือก



หมายเหตุ

- ระดับน้ำเป็นเพียงมาตรฐานโดยประมาณ คุณสามารถปรับระดับน้ำได้ตามความต้องการ สำหรับข้าวเหนียว ปริมาณน้ำที่กำหนดใช้สำหรับหุงข้าวเหนียวพื้นเมืองคุณสามารถปรับปรุงตามความเหมาะสมของชนิดข้าว
- ปรับระดับผิวน้ำข้าวให้เรียบ แล้วจึงค่อยปรับระดับน้ำ (มีฉนั้นข้าวอาจสกปรกทั่ว)
- อย่าใช้น้ำอ่อนพูดข้าว (อาจทำให้ข้าวแฉะ)
- หากใช้น้ำที่มีความกรดต่ำมาใส่ในภาชนะหุงข้าว อาจทำให้ข้าวและกินไม่อร่อยเมื่อหุงด้วยไฟเผา ในการหุงข้าวชนิดอื่น นอกเหนือไปจากข้าวข้าว ข้าวหอมมะลิ ไม่ว่าจะเป็นข้าวเหนียว ข้าวต้ม/ใจก หรือข้าวกล้อง

ระดับน้ำ

เลือกกฎเบบ	รายการ	ข้าวที่ใช้	ระดับน้ำ
หุงข้าว	ข้าวขาว	ข้าวตามหัว เท้าให้ข้าวน้ำปี ข้าวเมล็ดยา	ข้าวขาว
	ข้าวหอมมะลิ	ข้าวหอมมะลิ	ข้าวหอมมะลิ
	ข้าวญี่ปุ่น	ข้าวญี่ปุ่น	ข้าวญี่ปุ่น
	ข้าวเหนียว	ข้าวเหนียว	ข้าวเหนียว
หุงต้มพิเศษ	ข้าวกล้อง	ข้าวกล้อง	ข้าวกล้อง
	ข้าวต้มใจก	ข้าวตามหัว เท้าให้ข้าวน้ำปี ข้าวเมล็ดยา ข้าวหอมมะลิ	ข้าวต้มใจก
	ข้าวสม	ครัวยะเยือดหน้า 5	ครัวยะเยือดหน้า 5
	ข้าวขาว	ข้าวตามหัว เท้าให้ข้าวน้ำปี ข้าวเมล็ดยา	ข้าวขาว
หุงต้มพิเศษ	ข้าวหอมมะลิ	ข้าวหอมมะลิ	ข้าวหอมมะลิ
	ข้าวญี่ปุ่น	ข้าวญี่ปุ่น	ข้าวญี่ปุ่น

4

วางหม้อในลงใบในหม้อหุงข้าว




หมายเหตุ

- เช็ดภาชนะและก้นหม้อให้แห้ง ปัดลิ้นเปลกลบломอื่นๆ ออกให้หมด
- ตรวจสอบว่าไฟแน่นเจ้าหม้อหุงต้มด้วยสายไฟแล้วทำการร้อน ค่อยๆ หมุนจนกระแทกเข้าที่

5

ปิดฝาแล้วเลี้ยงปลอก



หมายเหตุ

- ต้องแน่ใจว่าใส่ฝาชั้นในและฝาภายนอกให้แน่นแล้ว
- ค่อยๆ ปิดฝาลงจนกระแทกที่ได้ยืนเลี้ยงคลิก

วิธีหุงข้าว

ดูหน้า 7

วิธีการใช้เมนูอัตโนมัติ

ดูหน้า 8

วิธีการอุ่นข้าวที่หุงสุกแล้ว

ดูหน้า 9

วิธีหุงข้าวพร้อมนึ่ง

ดูหน้า 10

วิธีการอบเด็ก

ดูหน้า 11

วิธีการต้ม

ดูหน้า 12

วิธีการตั้งเวลาล่วงหน้า

ดูหน้า 13

วิธีการนึ่งแบบกำหนดเอง

ดูหน้า 14

วิธีหุงข้าว

ข้าวขาว/ข้าวห้อมมะลิ/ข้าวญี่ปุ่น/ข้าวผสม/ข้าวเหนียว/ข้าวกล้อง/ข้าวต้ม/โจ๊ก

เวลาในการหุงข้าว

- * แรงดันไฟฟ้าที่ใช้ 220 โวลต์ อุณหภูมิห้อง 25°C อุณหภูมน้ำ 25°C
- * เวลาในการหุงข้าวยังขึ้นอยู่กับแรงดันไฟฟ้า อุณหภูมิห้อง อุณหภูมิของน้ำ และระดับน้ำร่วมถึงชนิดของข้าวที่ใช้ในการหุง


เวลาสูงสุดในการหุงข้าว (ประมาณเป็นนาที)

ข้าวขาว	ข้าวห้อมมะลิ/ข้าวญี่ปุ่น	ข้าวผสม/ข้าวเหนียว	ข้าวกล้อง	ข้าวต้ม/โจ๊ก	หุงด่วนพิเศษ
45~50	40~45	30~55	70~90	60~80	30 บริมาณข้าวไม่เกิน RZ-D10WF : 4 ถ้วย RZ-D18WF : 5 ถ้วย

หมายเหตุ : สำหรับโปรแกรมหุงด่วนพิเศษในปริมาณข้าวที่เกินจากตารางด้านบน เวลาในการหุงอาจเพิ่มขึ้นตามความเหมาะสม

1

กดปุ่ม [Menu] เพื่อเลือกประเภทการหุง




เมื่อเลือกปั๊กแล้ว หน้าจอจะแสดง

ประเภทการหุงที่เลือกอยู่ในขณะนั้น

ทุกครั้งที่กดปุ่ม

เครื่องหมาย ▶

แสดงการเลือกประเภทการหุงข้าว



ห้อมมะลิ/ข้าวญี่ปุ่น/ข้าวกล้อง/ข้าวผสม/ข้าวต้ม/โจ๊ก/ข้าวเหนียว

- หม้อหุงข้าวจะเริ่มการตั้งค่าเริ่มต้นที่เมื่อหุงข้าวขาวก่อนเสมอ
- หม้อหุงข้าวจะไม่จ้ำการตั้งค่า เมื่อเลือกเมนูข้าวขาว → ข้าวห้อมมะลิ/ข้าวญี่ปุ่น → ข้าวกล้อง → ข้าวผสม → ตุ่น → ตุ่น High → ข้าวต้ม/โจ๊ก → ข้าวเหนียว → นึ่ง → ตัก และกลับมาตั้งค่าเป็นข้าวขาวในครั้งต่อไปเสมอ

2

การเลือกรูปแบบในการหุงข้าวมี 2 แบบดื้อ

2.1 การหุงแบบปกติ

- กดปุ่มหุงข้าว [Cook/Reheat]



2.2 การหุงแบบเร่งด่วน

- กดปุ่มหุงเร่งด่วน [Rapid eco]



คุณจะได้ยินเสียงดนตรี จากนั้นหม้อจะเริ่มหุงข้าว

- * (เสียงดนตรีของการหุงแบบปกติจะแตกต่างกับการหุงแบบด่วน พิเศษ)

- หลังจากดุมหุงข้าวหรือหุงด่วนพิเศษจะไม่มีเวลาแสดงขั้นตอนหน้าจอ คุณจะได้ยินเสียงดนตรี จากนั้นหม้อจะเริ่มหุงข้าว (เสียงดนตรีการหุงแบบปกติจะแตกต่างจากการหุงด่วนพิเศษ) ช่วงที่ข้าวใกล้จะสุกจะแสดงจำนวนเวลาที่เหลือ (นาที) ดังตารางข้างล่างนี้ โดยเวลาจะลดลงครั้งละหนึ่งนาที

รูปแบบ ประเภท	การหุงปกติ	การหุงด่วนพิเศษ
ข้าวขาว	10	5
ข้าวห้อมมะลิ	15	-
ข้าวญี่ปุ่น	15	5
ข้าวกล้อง	10	-
ข้าวต้ม/โจ๊ก	5	-
ข้าวผสม	10	-
ข้าวเหนียว	10	-

หมายเหตุสำหรับการหุงข้าวขาว

- หลังจากที่เลือกปั๊กของหุงข้าวทุกครั้ง คุณสามารถเลือกรูปแบบการหุงได้ทันที โดยกดปุ่มหุงข้าว [Cook/Reheat] สำหรับการหุงแบบปกติ และกดปุ่มหุงเร่งด่วน [Rapid eco] สำหรับการหุงแบบด่วนพิเศษ


3

พรวนข้าวทันทีเมื่อหุงเสร็จ และได้ยินเสียงดนตรี

อุ่นให้ร้อน

- เมื่อหุงข้าวเสร็จสามารถอุ่นข้าวได้นานเกินกว่า 12 ชม. แต่คุณไม่ควรกระทำ เพราะข้าวอาจมีกลิ่นและสีที่เปลี่ยนไป จากเดิม
- การอุ่นจะทำให้เกิดหยดน้ำและสมภายในฝาขันใน หรือภายในตัวหม้อ ซึ่งจะทำให้ข้าวไม่แห้ง หม้อหุงข้าวไม่ได้ทำงานผิดปกติแต่อย่างไร

- ไฟอุ่นจะสว่างขึ้น และหม้อหุงข้าวจะทำการอุ่นข้าว ไปด้วยประทานข้าวทันทีที่หัวสูญ



- จะแสดงผลจะแสดงเวลาที่ใช้ในการอุ่น โดยแสดงเวลาตั้งแต่ 0 ชั่วโมง จนถึง 12 ชั่วโมง (เมื่อปั๊กขั้วโมงที่ 13 หน้าจอจะกลับมาแสดง เหตุน่องต้นเริ่มหุง)



- หากพรวนข้าวไม่ทั่ว ข้าวอาจดูดซับไอน้ำมาก ทำให้ข้าวเหนียวหรือแข็งมาก เกินไป
- ข้าวที่หุงตรงส่วนกลางแห้งอาจมีร่องบุ่มลงเล็กน้อย หรือข้าวที่ล้มผั้งกับผิวหม้อในจะขาดและนุ่มมากกว่าปกติ


เมื่อข้าวสุก หม้อหุงข้าวจะตัดการทำงานไปที่การอุ่นข้าว หากไม่ต้องการอุ่นข้าว ให้กดปุ่ม แล้วดึงปลั๊กออก

ก่อนรับประทาน

การใช้งาน

วิธีการใช้เมนูอัตโนมัติ (การทำอาหาร 40 เมนู)

- เวลาในการหุงและวิธีการทำอาหาร กรุณาดูที่คู่มือการทำอาหาร



แสดงตัวอย่างการเลือก
[Auto Recipe] เมนูที่ 3 ตั้งเวลา 91 นาที

คำเตือน

- อย่าใช้ผัดดักปะรังค์อกเหนือจากการทำอาหาร ตามที่ระบุไว้ในคู่มือการทำอาหาร
- กรุณายกไข่เป็นต้องเป็นฝาในระหว่างการทำอาหาร หากจำเป็นต้องเป็นฝาในระหว่างการทำหุ่ง ให้กดปุ่ม [Off] เพื่อหยุดการทำงานก่อนแล้ว จึงเปิดฝา (ระวังเกิดแพลพุพอง)

1

กด **เพื่อเลือกเมนูอาหารที่ต้องการ**

1-40
Auto Recipe
เมนู อัตโนมัติ

1-40
Cook/
Reheat
เมนู หุง/ผัด

Bread/Cake
Steam
Mixed/Sticky
Porridge

Auto Recipe

Time/Timer เวลา/ตั้งเวลา

Up
Down
aa

Slow Cook

1~40

White
Jasmine/
Japanese
Brown
Mixed Grain

Menu รายการ

Rapid ECO

2

กด **เลียงดนตรี (เลียงเตือน) ดังขั้น เริ่มให้ความร้อน**

Cook/
Reheat
เมนู หุง/ผัด

Cook/
Reheat
เมนู หุง/ผัด

แสดงเมนู

แสดงเวลา

Up
Down
aa

แสดงเมนู

แสดงเวลา

● ไฟ [Cook/Reheat] จะสว่างขึ้น

● เลียงดนตรี (เลียงเตือน) ดังขั้น การให้ความร้อน สิ้นสุดลง ให้นำอาหารที่ทำเสร็จแล้วไปไว้ในภาชนะอื่น

ข้อควรทราบ ● อย่าอุ่นหรือเก็บอาหารที่ทำเสร็จแล้ว ไว้ในฝาใน (หากไม่ปฏิบัติตาม ฟջูออริน์ ที่เคลือบอยู่บนหม้อในเกิดความเสียหายได้)

แสดงระยะเวลาในการให้ความร้อนเพื่อเลือก จนกว่าจะทำอาหารเสร็จโดยแสดงหน่วย

แสดงเมนู

แสดงเวลา

Cook/
Reheat
เมนู หุง/ผัด

● จำนวนชั่วโมงจะแสดงด้วย h

0:91

การอุ่นข้าวที่หุงสุกแล้ว

เคล็ดลับในการรักษาข้าวให้อุ่นและอร่อย

- เมื่อหุงเสร็จแล้ว หม้อหุงข้าวจะเปลี่ยนเป็นอุ่นโดยอัตโนมัติ และกรุณายกเลิกการอุ่นตามตารางด้านล่างนี้ หากเกิดกรณีที่เปลี่ยนข้าวแล้ว ข้าวสูญเสียคุณภาพ มักลิ้น หรือทำให้เหนียว ซึ่งขึ้นอยู่กับชนิดของข้าว

ชนิดข้าว	วิธีการหุง	การอุ่น
ข้าวขาว	WHITE	● การอุ่นโดยอัตโนมัติ สามารถอุ่นได้ไม่เกิน 24 ชั่วโมง และการอุ่นข้าวที่นานเกิน 24 ชั่วโมง อาจทำให้เกิดกลิ่นผิดปกติหรือเกิดการเปลี่ยนสีได้
ข้าวหอมมะลิ ข้าวปูน	JASMINE JAPANESE	● หลังจากการหุง เสร็จลิ้น จะเปลี่ยน เป็นอุ่นอัตโนมัติ ไฟ [Off/Warm] (อุ่น) ส่วน
ข้าวกล้อง	BROWN	● ห้ามทำการอุ่น (การอุ่นเป็นสาเหตุทำให้คุณภาพเปลี่ยน เกิดกลิ่น หรือทำให้เหนียว)
ข้าวเหนียว	STICKY	
ข้าวผสม	MIXED RICE	
ข้าวขาว ข้าวกล้อง	PORRIDGE	● เมื่อต้องการหยุด การอุ่นให้กด [OFF] ไฟ [Off/Warm] จะดับ

- ในระหว่างการอุ่น จะเกิดหยดน้ำบนด้านในของฝาและหม้อใน ซึ่งจะช่วยให้ข้าวไม่แห้งเกินไป และไม่ถือว่าเป็นความผิดปกติ

การใช้งาน

เคล็ดลับในการรักษาข้าวให้อุ่นและอร่อย

- คนข้าวเป็นบางครั้งในระหว่างการอุ่น
- หากมีข้าวเหลือไม่มาก จัดข้าวให้อยู่ตรงกลางหม้อในเท่าที่จะทำได้ (ป้องกันไม่ให้ข้าวแห้งหรือเหนียวเกินไป)
- ใช้เวลาในการอุ่นให้น้อยที่สุด อย่าอุ่นข้าวเกิน 24 ชั่วโมง (การอุ่นข้านานเกิน 24 ชั่วโมง อาจทำให้เกิดกลิ่นผิดปกติ หรือเกิดการเปลี่ยนสีได้ →)
- อย่าอุ่นนอกเหนือจากข้าวขาว, ข้าวหอมมะลิ, ข้าวปูน (ข้าวกล้อง, ข้าวต้ม, ข้าวผสม, ข้าวเหนียว)
- อย่าอุ่นข้าวที่หุงโดยไม่ได้ชาร์ฟไว้ในหม้อข้าว ในระหว่างการอุ่นอย่าอุ่นข้าวที่เย็นแล้ว
- สามารถห่อข้าวด้วยถุงพลาสติกและเก็บไว้ในช่องแข็ง แล้วนำมารออยเดาในโคลเวฟก็จะคงความอร่อยได้



วิธีการอุ่นข้าวให้ร้อนในระหว่างการอุ่น

- เมื่อรู้สึกว่าอุณหภูมิของข้าวต่ำไป กรุณามอุ่นข้าวให้ร้อนใหม่ตามความต้องการ
- ขอแนะนำว่าควรกำหนดให้ปริมาณข้าวต่ำกว่าระดับ 3 ของชีดบัน้ำสำหรับ [White Rice]

1

คนข้าวให้ทั่วในระหว่างการอุ่น
และเกลี่ยให้เรียบ

ข้อควรทราบ

- อย่าอุ่นข้าวให้ร้อนข้าวคลายครั้ง (หากไม่ปฏิบัติตาม อาจทำให้ข้าวแห้งหรือไหม้ได้)

2

กด ในระหว่างการอุ่น

- ไฟ [Cook/Reheat] กะเพริบ
- การอุ่นให้ร้อนใหม่ จะทำงานโดยอัตโนมัติประมาณ 10 นาที

- เมื่อข้าวยังร้อนอยู่หลังการหุงหรือเมื่อข้าวเย็นลงหลังการอุ่น เลี้ยงเตือนจะดังขึ้นและไม่สามารถทำการอุ่นข้าวให้ร้อนใหม่ได้

3

หลังจากหุงเสร็จลิ้น จะเปลี่ยนเป็นอุ่นอัตโนมัติ
ไฟ [Off/Warm] จะส่วน



- เมื่อต้องการหยุดการอุ่นให้กด Off ไฟ [Warm] จะดับ


วิธีหุงข้าวพร้อมนึ่ง

1

เตรียมข้าวที่จะทำการหุงและอาหารสำหรับนึ่ง


2

วางหม้อในหม้อหุงข้าว และนำถาดตื้นเบล็คกุ๊กที่ใส่อาหารกับเครื่องปรุงแล้วลงในถาดนึ่ง นำถาดนึ่งลงในหม้อใน ปิดฝาหม้อหุงข้าว




3

ปิดฝาและเลี้ยงปลั๊กเข้ากับเต้ารับ




4

กดปุ่มรายการ [Menu] เลือกประเภทการหุง [White Rice] หรือ [Jasmine Rice/Japanese Rice]




5

กดปุ่มหุงพร้อมนึ่ง [Double Cook] จะได้ยินเสียงดันตรี เมื่อหม้อเริ่มทำงาน เลี้ยงดันตรีจะแตกต่างกันระหว่างการหุงข้าวปกติและการหุงพร้อมนึ่ง



6

เมื่อข้าวสุกจะได้ยินเสียงดันตรี ไฟหุงข้าวจะดับ ไฟอุ่นสว่างขึ้นแทน




6.1 เปิดฝา นำอาหารที่นึ่งออก

6.2 พรานข้าวทันที เมื่อหุงข้าวสุก

- การเตรียมการหุงข้าว ให้ดูจากหน้า 6
- การเตรียมอาหารสำหรับนึ่ง ให้ดูจากหน้า 17-21
- บริมาณข้าวที่ใช้สำหรับโปรแกรมหุงพร้อมนึ่ง
 - 2 ถ้วย สำหรับหม้อหุงข้าวน้ำดี 1.0 ลิตร
 - 3 ถ้วย สำหรับหม้อหุงข้าวน้ำดี 1.8 ลิตร


- เช็คภายในและนอกให้แห้ง ปัดลิ่งแบกลปломอื่นๆออกให้หมด
- ตรวจสอบให้แน่ใจว่า หม้อในวงติดอยู่บนแผ่นความร้อน ต่อสายไฟทั้งชุดที่

- ทุกครั้งที่เลี่ยบปลั๊กใหม่ เครื่องหมาย ► จะแสดงในตำแหน่งข้างขวา



- ต้องแน่ใจว่าใส่ฝาขึ้นในและฝาระนาญไอน้ำแล้ว
- ต่อสายไฟทั้งชุดที่





- โปรแกรมหุงพร้อมนึ่งจะใช้ได้กับ [White Rice] หรือ [Jasmine Rice/Japanese Rice] เพื่อนั้น
- ปุ่มหุงพร้อมนึ่งจะไม่สว่างกับการหุงข้าวแบบอื่นๆ



- ไฟอุ่นจะสว่างขึ้นและหม้อหุงข้าวจะทำการอุ่นข้าวโดยอัตโนมัติ
- โปรดดับประทานข้าวทันที หลังข้าวสุก
- วิธีการอุ่นข้าว ดูที่หน้า 7






วิธีการอบเด็ก

1	เตรียมส่วนผสมเด็ก ปริมาณขึ้นอยู่กับขนาดของหม้อหุงข้าว ซึ่งมีระบุไว้ในคู่มือการทำอาหาร	
2	ท่านยรอนๆ หม้อในและก้นของหม้อในเล็กน้อยเพื่อไม่ให้เด็กติดกันหม้อใน	
3	เทส่วนผสมที่เตรียมไว้ลงในหม้อใน	
4	วางหม้อในลงไปในหม้อหุงข้าว	<ul style="list-style-type: none"> เช็คภายในและก้นหม้อในให้แห้ง ปัดลิ่งแปลงปลอมอื่นๆ ออกให้หมด ตรวจสอบให้แน่ใจว่าหม้อในวางติดอยู่บนแผ่นทำความร้อน ต้อยๆ หมูน จนกระแท้เข้าที่
5	ปิดฝาแล้วเลี้ยบ平整	<ul style="list-style-type: none"> ต้องแน่ใจว่าฝาชั้นใน และฝาระนาญไอน้ำแล้ว ต้อยๆ ปิดฝาลงจนกระแท้ได้อย่างคลิก
6	กดปุ่มรายการ [Menu] เพื่อเลือก “เด็ก”	<p>ทุกครั้งที่กดปุ่มรายการ  เครื่องหมายแสดงการเลือกประเภทการหุงข้าว → ข้าวห่มมะลิ/ข้าวถั่วปู → ข้าวคล่อง → ข้าวผัด → ตุน → ตุน High → ข้าวต้ม/โจ๊ก → ข้าวเหนียว → นึ่ง → เด็ก ตามลำดับ ► จะเปลี่ยนไปครั้งละเมนูเงินเด็ก</p>   
7	กดปุ่มลด/เพิ่ม [Down/Up] เพื่อตั้งเวลาสำหรับเด็ก	<p>ทุกครั้งที่กดปุ่มเพิ่ม [Up] เวลาจะเพิ่มขึ้นครั้งละ 5 นาที หรือกดปุ่มลด [Down] เวลาจะลดลงครั้งละ 5 นาที เช่นตั้งตัวอย่างข้างต้นเป็นการตั้งเวลาสำหรับเด็กนาน 40 นาที</p>   
8	กดปุ่มหุงข้าว [Cook/Reheat]	<p>คุณจะได้ยินเสียงดังตัวไฟหุงข้าวจะติดและจำนวนเวลาสำหรับการอบเด็กจะดับพริบ จากนั้นหม้อหุงข้าวจะเริ่มทำการอบเด็กตามจำนวนเวลาที่ได้ตั้งเวลาสำหรับการอบเด็ก</p> <p>หน้าจอจะแสดงเวลาที่เหลืออยู่ โดยตัวเลขจะลดลงทุกๆ หนึ่งนาที</p> <p>ระหว่างการอบเด็ก อย่าเปิดฝาหม้อหุงข้าว เพราะจะทำให้เด็กไม่สุก</p> <p>หมายเหตุ</p> <ul style="list-style-type: none"> ระยะเวลาในการอบเด็ก โดยประมาณ ให้อ่านตามคำแนะนำในคู่มือการทำอาหารที่แนบมาด้วย  
9	เมื่อเด็กสุกจะได้ยินเสียงดนตรี ไฟหุงข้าวจะดับไฟอุ่นจะสว่างขึ้นแทน ให้กดปุ่มปิด [Off/Warm] เพื่อยกเลิกการทำงานของหม้อหุงข้าว หลังจากนั้นให้เปิดฝาทันที	
10	ดึงปลั๊กออก และเก็บสายไฟให้เรียบร้อย	
11	ยกหม้อในออกจากตัวหม้อหุงข้าว และวางทิ้งไว้ให้เย็นประมาณ 3-5 นาที	<ul style="list-style-type: none"> ควรรวมถึงมือกันความร้อนหรือผ้าเพื่อจับหม้อในในการนำเด็กหรือขนมปังออกจากหม้อใน 
12	เด็ก : ตกแต่งหน้าเด็กให้สวยงามตามความต้องการ	

การซ่อน

วิธีการตั้ง

- | | |
|---|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 | เตรียมส่วนผสมอาหารสำหรับตุ๋น ปริมาณขึ้นอยู่กับขนาดของหม้อหุงข้าว ซึ่งบางรายการอาหารมีระบุไว้ในคู่มือ การทำอาหารที่แนะนำหม้อหุงข้าว |
| 2 | เก็บส่วนผสมที่เตรียมไว้ลงในหม้อใน |
| 3 | วางหม้อในลงในหม้อหุงข้าว |
| 4 | ปิดฝาแล้วเสียบปลั๊ก |
| 5 | <p>กดปุ่มรายการ [Menu] เพื่อเลือก “ตุ๋น”</p>  <ul style="list-style-type: none"> หากกดปุ่ม |
| 6 | <p>กดปุ่มลด/เพิ่ม [Down/Up] เพื่อตั้งเวลาสำหรับตุ๋น</p>  <ul style="list-style-type: none"> หากกดปุ่ม |
| 7 | <p>กดปุ่มหุงข้าว [Cook/Reheat]</p>  <ul style="list-style-type: none"> ไฟติด |
| 8 | ดึงปลั๊กออกจากเตาครัว |
| | <ul style="list-style-type: none"> เช็คภายในและกันหม้อน้ำให้แห้ง ปัดสิ่งแปลกปลอมอื่นๆ ออกให้หมด ตรวจสอบให้แน่ใจว่าหม้อในวางติดอยู่บนแผ่นทำความร้อน ค่อยๆ หมุนจนกระแท็กเข้าที่ ต้องแน่ใจว่าฝาชนในและฝาระนาญไอน้ำแล้ว ค่อยๆ ปิดฝาลงจนกระแทกที่ตั้งได้ยินเสียงคลิก <p>• หากตั้งเวลาสำหรับการตุ๋นจะมี ▶ และเครื่องหมาย ▶ และดูเหมือนตัวหนังสือ “กำหนดเวลา” พร้อมกับการตั้งเวลาสำหรับการตุ๋นจะมี ▶ โดยไฟหุงข้าวจะกะพริบขณะทำงาน</p>  <p>ตัวเลขและ Timer กะพริบ</p> |
| | <ul style="list-style-type: none"> หากตั้งเวลาสำหรับการตุ๋นเพิ่ม [Up] เวลาจะเพิ่มขึ้นค้างลัง 30 นาที หรือกดปุ่มลด [Down] เวลาจะลดลงค้างลัง 30 นาที เช่นตั้งตัวอย่างข้างต้นเป็นการตั้งเวลาสำหรับตุ๋นนาน 2 ชั่วโมง 30 นาที  <p>ตัวเลขและ Timer กะพริบ</p> <p>หมายเหตุ</p> <ul style="list-style-type: none"> ระยะเวลาในการตุ๋นขึ้นอยู่กับประเภทอาหารที่จะตุ๋น |
| | <ul style="list-style-type: none"> คุณจะได้ยินเสียงดังดรี ไฟหุงข้าวจะติดและจำนวนเวลาสำหรับการตุ๋นจะหมุนกะพริบ จากนั้นหม้อหุงข้าวจะเริ่มทำการตุ๋นตามจำนวนเวลาที่ได้ตั้งเวลาสำหรับการตุ๋น หน้าจอจะแสดงเวลาที่เหลืออยู่ โดยตัวเลขจะลดลงทุกๆ หนึ่งนาที เมื่อตุ๋นครบตามจำนวนเวลาที่ตั้งไว้ ไฟหุงข้าวจะตั้งไฟแสดงการอุ่นจะสว่างเพื่อ提醒เมื่อสิ้นสุดการทำงาน  <p>Bread/Cake
Steam
Mixed/Sticky Porridge
Slow Cook</p> <p>2 H 30 M</p> <p>Timer ▶ White/Jasmine/Brown/Mixed Grain</p> <p>Off/Warm</p> |

วิธีการตั้งเวลาล่วงหน้า

เมื่อคุณตั้งเวลาสิ้นสุด (การหุงแบบตั้งเวลาล่วงหน้า)

คุณสามารถตั้งเวลาหุงข้าวล่วงหน้าได้สูงสุด 12 ชม. 30 นาที

หมายเหตุ

- การหุงแบบตั้งเวลาล่วงหน้า ใช้ได้กับการหุงข้าวขาว ข้าวหอมมะลิ ข้าวญี่ปุ่น ข้าวผัด/ข้าวเหนียว ข้าวกล้อง และข้าวต้ม/โจ๊ก
- โปรดอย่าใช้การหุงแบบตั้งเวลาล่วงหน้า เมื่อหุงข้าวอบปูรุสหรือข้าวผัดเครื่องปูรุสอื่นๆ เพราะส่วนผสมต่างๆ ของเครื่องปูรุสอาจทำให้หุงข้าวได้ไม่ดีหรือไม่น่ารับประทาน

(ตัวอย่าง) เวลาปัจจุบันตอนเย็น 19.00 น. เราต้องการตั้งเวลาล่วงหน้าสำหรับหุงข้าวให้สุกในตอนเช้า 6.30 น. ของวันรุ่งขึ้น ดังนั้น ให้ตั้งเวลาไว้ 11 ชั่วโมง 30 นาที ตามผลิต่างของเวลาที่ต้องการกับเวลาปัจจุบัน

1 กดปุ่ม ลด เพิ่ม [Down/Up] ตามผลิต่างของเวลา



เลือกประเภทการหุงที่ต้องการ


ทุกครั้งที่กดปุ่มลด [Down] เวลาจะลดลง ครั้งละ 30 นาที หรือกดปุ่มเพิ่ม [Up]



เวลาจะเพิ่มขึ้นครั้งละ 30 นาที เช่นเดียวกัน ตัวอย่างเช่นด้าน เป็นการตั้งเวลานาน 11 ชั่วโมง 30 นาที

- ไฟทุกขั้วจะกะพริบขณะทำการตั้งเวลา

2 กดปุ่มหุงข้าว [Cook/Reheat]



กดปุ่มหุงข้าว [Cook/Reheat] การตั้งเวลาจะเริ่มทำงาน

ไฟทุกขั้วจะดับและเสียงสัญญาณจะดังขึ้น

หน้าจอจะแสดงเวลาที่เหลืออยู่ โดยตัวเลขจะลดลงทุกๆ หนึ่งนาที

เมื่อหุงข้าวสุก ไฟแสดงการอุ่นจะสว่างพร้อมกับมีเสียงสัญญาณแสดง การสิ้นสุดการหุงข้าว

หมายเหตุ


- คุณจะไม่สามารถหุงข้าวโดยการตั้งเวลาได้ หากยังไม่ได้กดปุ่มหุงข้าว [Cook/Reheat] เพื่อให้มหุ่งข้าวเริ่มทำงาน

ข้อแนะนำ

- กดปุ่มปิด [Off/Warm] เพื่อยกเลิกการตั้งเวลา
- การกดปุ่มลักษณะการตั้งเวลาจะทำให้การตั้งเวลาหายไป และตัวตั้งเวลาจะกลับไปที่ต่อไปนี้
- เวลาที่ใช้ในการหุงอาจคาดเคลื่อนกับเวลาที่ตั้งไว้เล็กน้อย ขึ้นอยู่กับอุณหภูมิของน้ำ อุณหภูมิห้อง แรงดันไฟฟ้า หรือ ระดับของน้ำ

วิธีการนึ่งแบบกำหนดเอง

1 การนึ่งอาหารอื่น



ภาชนะ
น้ำ

- ใส่น้ำลงหม้อน้ำใน : รุ่น 1.0 ลิตร ที่ชีดบอร์ดบนน้ำเลข 3 (ข้าวหอมมะลิ) : รุ่น 1.8 ลิตร ที่ชีดบอร์ดบนน้ำเลข 4 (ข้าวหอมมะลิ)
- นำภาชนะลงหม้อน้ำ
- ใส่ผักหรืออาหารลงในภาชนะ
- การวางหม้อน้ำใน (ฐานยัลลาร์เดินหน้า 6)

2 การนึ่งข้าวเหนียว

การเตรียมการนึ่งข้าวเหนียว

ตวงข้าวด้วยถ้วยตวงที่ได้มาพร้อมหม้อหุงข้าว

- ใส่น้ำให้มากพอแล้วข้าวข้าว จากนั้นเพ้นท์ทังทันที
- ทำข้าวตั้งต้น “ข้าวข้าว ⇨ เทน้ำทิ้ง” จนน้ำสระออก
- แข็งข้าวในน้ำสะอาด 1 ชั่วโมง


3 การนึ่งข้าวเหนียว




* ก่อนนึ่งข้าวเหนียว ควรแข็งข้าวในน้ำ 1 ชั่วโมง

- ใส่น้ำลงหม้อน้ำใน : รุ่น 1.0 ลิตร ที่ชีดบอร์ดบนน้ำเลข 3 (ข้าวหอมมะลิ) : รุ่น 1.8 ลิตร ที่ชีดบอร์ดบนน้ำเลข 4 (ข้าวหอมมะลิ)
- วางตัวข้าวบนที่ผ่านการซูบน้ำลงในภาชนะ หลังจากนั้นนำภาชนะลงหม้อน้ำ
- ใส่ข้าวที่ผ่านการแขวน 1 ชั่วโมง ลงในภาชนะ
- พับชาตัวข้าวบนขั้นมาปิดข้าวด้านบนแล้วปิดฝ่า
- (ถ้าไม่ใช้ตัวข้าวบนรองด้านใน อาจทำให้ข้าวเหนียวเนื้้มีสุก)


4 เลี้ยงปลั๊กเข้ากับเตารับ




- ทุกครั้งที่เลี้ยงปลั๊กใหม่ เครื่องหมาย ► จะแสดงที่ตำแหน่งข้อความ “ข้าวขาว” (White Rice)



5 กดปุ่มรายการ [Menu] เพื่อเลือกรายการนึ่ง “Steam”




- ทุกครั้งที่กดปุ่มรายการ [Menu] เครื่องหมาย ► แสดงการเลือกประเภทการหุง จะเลื่อนไปคละเมนู ข้าวขาว → ข้าวหอมมะลิ/ข้าวญี่ปุ่น → ข้าวกล้อง → ข้าวผлов → ตุ่น → ตุ่น High → ข้าวต้มโภค → ข้าวเหนียว → นึ่ง → เค้า
- ข้อความ “Timer” พร้อมกับเวลาสำหรับการนึ่งจะหายไป โดยไฟฟูงข้าว จะกะพริบขณะตั้งเวลา



6 กดปุ่มลด/เพิ่ม [Down/Up] เพื่อตั้งเวลาสำหรับนึ่ง




- ทุกครั้งที่กดปุ่มเพิ่ม [Up] เวลาจะเพิ่มขึ้นครั้งละ 1 นาที หรือกดปุ่มลด [Down] เวลาจะลดลงครั้งละ 1 นาที เช่น ตัวอย่างข้างต้นเป็นการตั้งเวลาสำหรับนึ่งนาน 38 นาที



7 กดปุ่มหุงข้าว [Cook/Reheat]




- คุณจะได้ยินเสียงดันตรี ไฟฟูงข้าวจะติดและจำนวนเวลาสำหรับนึ่งจะหยุดกะพริบ จากนั้นหม้อหุงข้าวจะเริ่มทำการนึ่งตามเวลาที่ได้ตั้งไว้
- หน้าจอจะแสดงเวลาที่เหลืออยู่ โดยตัวเลขจะลดลงทุกๆ หนึ่งนาที



- เมื่อครบเวลาที่ตั้งไว้ ไฟฟูงข้าวจะดับ ไฟแสดงการอุ่นจะสว่างพร้อมกับมีเสียงัญญาณแสดงการสิ้นสุดการนึ่ง

8 ดึงปลั๊กออกจากเตารับ



- หลังจากนึ่งเสร็จ ไม่ควรเปิดฝาโดยทันที ควรรอประมาณ 2-3 นาที
- หลังจากการใช้งานหม้อหุงข้าว ควรกดปุ่ม ปิด/อุ่น [Off/Warm] และดึงปลั๊กออกทุกครั้งเพื่อความปลอดภัย

การทำความสะอาด



การทำความสะอาดสำหรับหม้อหุงข้าว

- ก่อนทำความสะอาด ให้ลอกบล็อกและรอให้ตัวหม้อเย็นลงก่อน
- ห้ามใช้น้ำมันเบนzen ทินเนอร์ ผงชีด หรือแบปรังซัดทำความสะอาดหม้อหุงข้าว (เพราะอาจทำให้สารเคลือบหม้อเสียหาย)

ตัวหม้อ/ฝา


เช็ดด้วยผ้าขนหน้าหมาดๆ



พาร์ฟี/ถ้วยตวง/ภาชนะ/ภาดดึบเบล็คกิ้ง


เช็ดด้วยวัสดุเนื้อนุ่ม เช่น พองน้ำ โดยล้างด้วยน้ำยาล้างจาน

③ ล้างทำความสะอาด



วิธีการใส่

- ติดฝาครอบระหว่างฝาบนเข้ากับฝาระนาฯ ไอน้ำ เล็บฝาครอบจะงายไปน้ำเข้ากับฝาระนาฯ ไอน้ำ ล็อกให้ตรงตำแหน่ง
- กดฝาครอบระหว่างฝาบนเข้ากับฝาระนาฯ ไอน้ำ เข้ากับฝาระนาฯ ไอน้ำ
- ใส่ฝาระนาฯ ไอน้ำเข้ากับฝา กดบริเวณกึ่งกลางของฝาระนาฯ ไอน้ำให้ชิดสุด กับส่วนด้านล่าง




ฝาระนาฯ ไอน้ำ (ล้างทุกครั้งหลังใช้งาน)

ดึงออกจากตัวหม้อแล้วเช็ดด้วยวัสดุเนื้อนุ่ม เช่น พองน้ำ โดยล้างด้วยน้ำยาล้างจาน

วิธีดึงออกจากตัวหม้อ

- ถอดฝาระนาฯ ไอน้ำออก จากหม้อ
- ถอดฝาระนาฯ ไอน้ำออกจากฝาครอบระหว่างฝาบน




ควรรีดเหยดน้ำออกทุกครั้งหลังการใช้งาน

แผ่นทำความสะอาด

เช่นเชือร์ตรวจจับอุณหภูมิ

หากน้ำค้างในหม้อไม่สะอาด ให้ชุบฟองน้ำด้วยผงซักฟอกอย่างอ่อน (น้ำยาล้างจาน) และเช็ดให้แห้ง
เวลาอุ่นข้าว



เช็ดข้าวหรือความเหนียวออกจากฝาขันใน เพราะอาจทำให้ข้าวแห้ง เวลาอุ่นข้าว

หม้อใน

เช็ดด้วยวัสดุเนื้อนุ่ม เช่น พองน้ำ หากยังไม่สะอาด ให้ชุบฟองน้ำด้วยผงซักฟอกอย่างอ่อน (น้ำยาล้างจาน) และเช็ดให้แห้ง

หมายเหตุ

- ข้าวอาจแห้งได้เมื่อตากหม้อในเลี้ยงรูป เพื่อให้หม้อในคงรูป ควรจัดถือด้วย ความระมัดระวัง
- เพื่อไม่ให้สารเคลือบฟู่ออกเร็วเสียหาย
 - ควรใช้ทัพพีที่วางพื้นหม้อหุงข้าว
 - ห้ามล้างในขณะที่ยังมีช้อนหรือถ้วยค้างอยู่ในหม้อ
 - ห้ามใช้น้ำอุ่นลวก
 - ห้ามขัดผิวด้านในหม้อด้วยผงซักฟอกหรือแบปรังซัด
 - ใช้กาชณะอ่อนใน การชาร์ข้าวแทน
- สารเคลือบฟู่ออกเร็วจะหลุดลอกเมื่อใช้งานไประยะหนึ่ง จะน้ำ โปรดใช้อย่างระมัดระวัง
เมื่อใช้หม้อในไปลักษณะ สีด้านในอาจไม่สม่ำเสมอ กัน ซึ่งไม่มีผลต่อการหุงข้าว และไม่เป็นอันตรายต่อสุขภาพแต่อย่างใด


การวิเคราะห์ปัญหาที่เกิดขึ้น

โปรดตรวจสอบตามหัวข้อต่อไปนี้ก่อนติดต่อศูนย์บริการ

- หากตรวจสอดคล้องตามหัวข้อข้างต้นแล้วยังไม่สามารถแก้ปัญหาได้ กรุณารีดติดต่อร้านที่คุณซื้อห้องน้ำมือใหม่
 - หากหัวแม่ในเสียงรูป หรือสารเดื่อเสียงฟลูอิโอนหลุดลอกออก โปรดรีซื้อตัวหัวน้ำในใหม่
 - หากจราแสงผลแสดง H1~H7 กรุณารีดติดต่อร้านที่คุณซื้อห้องน้ำมือใหม่

เมื่อไฟฟ้าเกิดดับ

- เมื่อไฟฟ้าเกิดดับขั้นตอนทำการหุ้นหัวหรือสูบหัว หม้อหุ้นหัวจะหยุดการทำงานและจอแสดงผลจะแสดงเมื่อต้นไฟฟ้าเริ่ง (ไม่มีข้อความใดๆ แสดงอยู่บนหน้าจอแสดงผล)
 - เมื่อไฟฟ้าติดใหม่อีกครั้ง หน้าจอแสดงผลจะแสดงเครื่องหมาย “- -” ที่กำลังกะพริบ เป็นการแจ้งให้ทราบว่าได้มีการเกิดไฟฟ้าดับและหม้อหุ้นหัวได้หยุดการทำงาน
 - เครื่องหมาย “- -” จะหายไปถ้าคุณกดปุ่ม [Off/Warm]
 - ถ้าหัวที่หุงยังไม่สุก ก็ ร้อนกอกปุ่ม [Cook/Reheat] เพื่อเริ่มการหุงอีกครั้ง
 - ถ้าหัวที่หุงสุกเรียบร้อยแล้วคุณต้องการที่จะสูบหัว กดปุ่ม [Off/Warm] อีกครั้ง และไฟอ่อนจะสว่าง



หมายเหตุ

- เมื่อข้าวที่หงับไม่สุกดี กรุณาเช็คขอแสดงผลทุกครั้ง ถ้าเครื่องหมาย “- -” กำลังจะพริบ หม้อหุงข้าวยังคงทำงานปกติโดยการแสดงเครื่องหมายไฟดับ
 - ในบางกรณีของไฟตั้งเป็นเวลานานและเมื่ออุณหภูมิของข้าวลดลง เครื่องหมาย “- -” อาจไม่แสดง ดังนั้น หากครั้งที่ข้าวหงับไม่สุก กรุณาลองหุงใหม่อีกครั้ง

คู่มือการทำอาหาร โปรแกรมหุงพร้อมนึ่ง

* ปริมาณข้าวที่ใช้สำหรับโปรแกรมหุงพร้อมนึ่ง

2 ถ้วย สำหรับหม้อหุงข้าวขนาด 1.0 ลิตร และ 3 ถ้วย สำหรับหม้อหุงข้าวขนาด 1.8 ลิตร

กุ้งบีบซีอิ๊ว



วิธีทำ

- ล้างกุ้งก้ามgarum ตัดหนวด ตัดดชา ผ่าเป็นเส้นก้านหางตามยาวออกเป็น 2 ชิ้น
- ผสมราดั้กซี กระเทียม พริกไทยบ่ำ และเครื่องปูรุสพัทท์หมัดเข้าด้วยกัน
- เรียงกุ้งก้ามgarumลงในภาชนะด้วยเนื้อกุ้ง ราดล้วนพอเข้ากันที่ 2 ลงบนตัวกุ้ง
- ใส่ข้าว* และเติมน้ำเปล่าตามระดับของหม้อหุงข้าว วางภาชนะ ตามด้วยภาชนะด้วยเนื้อกุ้งที่ใส่อาหารไว้ ปิดฝาหม้อ กดปุ่มรายการ [Menu] เลือกรายการหุงตามชนิดของข้าว
- กดปุ่มหุงพร้อมนึ่ง [Double Cook] เมื่อมีสัญญาณดัง เปิดฝาหม้อ ยกอาหารออกจากหม้อ จัดใส่จาน ตกแต่งด้วยพริกซีฟ้าและผักชี จัดเลิศพร้อมๆ

ไก่เชียงໄວ



วิธีทำ

- ตัดแต่งอกไก่ให้ได้ชิ้นสวยงาม ล้างให้สะอาด พักไว้ให้สะเด็ดน้ำ
- ผสมล้วนพอสมควรให้เข้ากัน ใส่อกไก่คลุกเคล้าให้เข้ากัน หมักไว้ 1 ชั่วโมง
- เรียงอกไก่ลงในภาชนะด้วยเนื้อกุ้ง ราดน้ำหมักให้ลิ้งเนินไว้ โรยต้นหอม
- ใส่ข้าว* และเติมน้ำเปล่าตามระดับของหม้อหุงข้าว วางภาชนะ ตามด้วยภาชนะด้วยเนื้อกุ้งที่ใส่อาหารไว้ ปิดฝาหม้อ กดปุ่มรายการ [Menu] เลือกรายการหุงตามชนิดของข้าว
- กดปุ่มหุงพร้อมนึ่ง [Double Cook] เมื่อมีสัญญาณดัง เปิดฝาหม้อ ยกอาหารออกจากหม้อ หั่นไก่เป็นชิ้น ตกแต่งภาชนะที่ล้วนไว้ วางไก่ที่หั่นไว้ ราดด้วยน้ำที่เหลือจากการนึ่ง ตกแต่งด้วยผักชี ต้นหอม และพริกซีฟ้า จัดเลิศพร้อมๆ

ส่วนผสม (2-3 ที่)

กุ้งก้ามgarum

(ตัวละประมาณ 120-140 กรัม)	3	ตัว
รากผักชีไซอกະເອີດ	1	ช้อนชา
กระเทียมໂຂລກະເອີດ	1	ช้อนชา
พริกไทยบ่ำ	1/8	ช้อนชา
ซอสเท็ดหอม	2	ช้อนชา
ชีอิ๊วขาว	1	ช้อนโต๊ะ
น้ำตาลทราย	1	ช้อนชา
น้ำมันงา	1	ช้อนโต๊ะ
ผักชีสำหรับตกแต่ง		
พริกซีฟ้าสีแดงหั่น成เส้น		
ข้าวสาร, น้ำเปล่า		

คู่มือสอนการทำอาหาร

ส่วนผสม (2-3 ที่)

เนื้อออกไก่

(ชิ้นละประมาณ 180 กรัม)	2	ชิ้น
ต้นหอมหั่นท่อน 1 นิ้ว	1	ตัน
ผักชี	3	ช่อ
พริกซีฟ้าสีแดงหั่นเส้น	1/2	เม็ด
ต้นหอมซอย	1/4	ถ้วย
แตงกวาญี่ปุ่นหั่นแต่งตามชอบ, ข้าวสาร, น้ำเปล่า		

ส่วนผสมซอส

โซย (ชีอิ๊วญี่ปุ่น)	1 1/2	ช้อนโต๊ะ
จิ๊กไส้	2	ช้อนชา
น้ำมันงา	2	ช้อนชา
เนยถั่ว	2	ช้อนชา
กระเทียมลับละเอียด	1	ช้อนชา
พริกไทยบ่ำ	1/4	ช้อนชา
ชิงแก่ลับ	1	ช้อนโต๊ะ

บูนี่แบบพัสด์พริก



วิธีทำ

1. ล้างปูให้สะอาด แกะกระดองออกจากด้า ทุบเปลือกให้แตก ตัดเป็นชิ้น พักไว้
 2. โขลกพริกชี้ฟ้า หอมแดง กระเทียม ให้ละเอียด
 3. ผสมซอสมะเขือเทศ น้ำมันพีช น้ำพริกเผา น้ำมันถั่ยชู น้ำตาลทราย เกลือป่น แป้งมันสำปะหลัง น้ำซุป ไข่ไก่ ล้วนผสมในข้อที่ 2 หомหัวใหญ่ พริกชี้ฟ้า และต้นหอม คนให้เข้ากัน
 4. ใส่ปูและซิง ลงครุกเคล้าให้เข้ากัน ตักใส่ถาดตื้นเบล็คกิ้ง
 5. ใส่ข้าว* และเติมน้ำเปล่าตามระดับของหม้อหุงข้าว วางถาดนึง ตามด้วยถาดตื้นเบล็คกิ้งที่ใส่อาหารไว้ ปิดฝาหม้อ
 6. กดปุ่มหุงพร้อมนึ่ง [Double Cook] เนื้อมีลักษณะเด้ง เปิดฝาหม้อ ยกอาหารออกจากหม้อ
 7. คุกเคล้าให้เข้ากัน จัดใส่จาน ตกแต่งด้วยผักชี จัดเลิศฟร้อนๆ
- หมายเหตุ : - มีรสเค็ม หวาน และอมเปรี้ยว

ปลาทิมะบูนี่เช็อว์



วิธีทำ

1. ล้างปลาทิมะให้สะอาด ใช้ตะแกรงพักไว้ให้สะเด็ดน้ำ
2. วางปลาทิมะลงในถาดตื้นเบล็คกิ้ง วางหม้อน้ำลงชั้น ชิง ปรุงรสด้วยซีอิ๊วขาว น้ำมันงา
3. ใส่ข้าว* และเติมน้ำเปล่าตามระดับของหม้อหุงข้าว วางถาดนึง ตามด้วยถาดตื้นเบล็คกิ้งที่ใส่อาหารไว้ ปิดฝาหม้อ กดปุ่มรายการ [Menu] เลือกรายการหุงตามชนิดของข้าว
4. กดปุ่มหุงพร้อมนึ่ง [Double Cook] เนื้อมีลักษณะเด้ง เปิดฝาหม้อ ยกอาหารออกจากหม้อ
5. จัดใส่จานโดยด้วยต้นหอม พริกชี้ฟ้า จัดเลิศฟร้อนๆ

ล้วนผสม (2-3 ที่)

ปูทะเลสด (น้ำหนักประมาณ 500 กรัม)	1	ตัว
พริกชี้ฟ้าสีแดงหั่นవีน์ สำหรับโซลก	1/3	ถ้วยตวง
พริกชี้ฟ้าสีแดงผ่านเมล็ดออก สับหยาบ	1	เม็ด
หอมแดงซอย	2	ช้อนโต๊ะ
ซิงชอย	1	ช้อนโต๊ะ
กระเทียมสับหยาบ	1	ช้อนโต๊ะ
หอยหัวใหญ่สับหยาบ	1/2	ถ้วยตวง
ซอสมะเขือเทศ	4	ช้อนโต๊ะ
น้ำมันพีช	1	ช้อนโต๊ะ
น้ำพริกเผา	3	ช้อนโต๊ะ
น้ำมันถั่ยชู	1	ช้อนชา
น้ำซุปไก่	2	ช้อนโต๊ะ
น้ำตาลทราย	5	ช้อนชา
เกลือป่นหยาบ	1 1/2	ช้อนชา
แป้งมันสำปะหลัง	1	ช้อนชา
ไข่ไก่	1	ฟอง
ต้นหอมหั่นท่อนยาว 1 นิ้ว	1	ตัน
ผักชีดเป็นชือ	3	ช่อ
ข้าวสาร, น้ำเปล่า		

ล้วนผสม (2-3 ที่)

ปลาทิมะ		
(ชิ้นละประมาณ 100 กรัม)	2	ชิ้น
หมูสามชั้นหั่นชิ้นบางๆ	30	กิโล
ซีอิ๊วขาว	1-1 1/2	ช้อนโต๊ะ
น้ำมันงา	1	ช้อนชา
ซิงชอย	3	ช้อนโต๊ะ
ต้นหอมซอยเล้น	1	ตัน
พริกชี้ฟ้าสีแดงหั่นเฉ็น	1/2	เม็ด
ข้าวสาร		
น้ำเปล่า		

เต้าหู้บ้ำแดง



วิธีทำ

- ผัดน้ำมันพืช กระเทียม ปรุงรสด้วยซอสเห็ดหอม ชีวิชรา น้ำตาลทราย น้ำมันงา พริกไทยป่น น้ำขุ่นไก่ และแป้งมันสำปะหลัง คนให้เข้ากัน
- ใส่เห็ดหอม เต้าหู้ ต้นหอม คุกเกล็ดล้าให้เข้ากัน ตักไส้ถูกด้วยมือ
- ใส่ข้าว* และเติมน้ำเปล่าตามระดับของหม้อหุงข้าว วางแผนดึง ตามด้วยกัดดึบเบล็คกู๊ฟให้อาหารໄร์ ปิดฝาหม้อ กดปุ่มรายการ [Menu]
- เลือกรายการหุงตามชนิดของข้าว
- กดปุ่มหุงพร้อมนึ่ง [Double Cook] เมื่อมีสัญญาณดัง เปิดฝาหม้อ ยกอาหารออกจากหม้อ
- จัดเสิร์ฟร้อนๆ จัดเสิร์ฟร้อนๆ

กาโdo กาโdo



วิธีทำ กาโdo กาโdo

- ใส่กะหล่ำปี แครอท มันผั่ง ผักบุ้ง ถั่วฝักยาว และถั่วงอก ลงในภาชนะดึบเบล็คกู๊ฟ
- ใส่ข้าว* และเติมน้ำเปล่าตามระดับของหม้อหุงข้าว วางแผนดึง ตามด้วยกัดดึบเบล็คกู๊ฟให้อาหารໄร์ ปิดฝาหม้อ กดปุ่มรายการ [Menu]
- เลือกรายการหุงตามชนิดของข้าว
- กดปุ่มหุงพร้อมนึ่ง [Double Cook] เมื่อมีสัญญาณดัง เปิดฝาหม้อ ยกผ้าออกจากหม้อ
- จัดผ่านน้ำเปล่าจาน วางแผนดึง แล้วต้ม จัดเสิร์ฟร้อนๆ ซอสถั่ว

วิธีทำ ซอสถั่ว

- โอลิกพิริกชี้ฟ้ากับเกลือป่น (1) พอหายาน ใส่หอยแಡง กระเทียม กระนิย โอลิกให้ละเอียด
- ใส่น้ำมันพืชลงในหม้อใน กดปุ่มหุงด่วนพิเศษ พอหอยร้อน ใส่ส่วนผสมน้ำพิริกที่โอลิกไว้ ผัดให้เข้ากันประมาณ 5 นาที
- ใส่น้ำขุ่นไก่ ปรุงรสด้วยเกลือป่น (2) น้ำมะขามเปียก น้ำมันงา น้ำตาลบืน ชีวิชรา วางแผนดึง แล้วถักสิ่ง คนให้เข้ากัน ปิดฝาหม้อไว้ เปิดดูบ่อยๆ เคี่ยวจนซอลขึ้น ปิดไฟ เทไส้ภาชนะ

ส่วนผสม (3-4 ที่)

เต้าหู้สีเหลืองหั่นชิ้น	250	กรัม
กระเทียมสับหยาบ	1	ช้อนโต๊ะ
เห็ดหอมสดตัดหัวผ่าครึ่ง	6	ดอก
น้ำมันพืช	1	ช้อนโต๊ะ
ซอสเห็ดหอม	1	ช้อนโต๊ะ
ชีวิชรา	2	ช้อนชา
น้ำตาลทราย	1	ช้อนชา
น้ำมันงา	2	ช้อนชา
พริกไทยป่น	1/4	ช้อนชา
น้ำขุ่นไก่	1/2	ถ้วยดาว
แป้งมันสำปะหลัง	2	ช้อนชา
ต้นหอมหั่นท่อน 1 นิ้ว	2	ตัน
พริกชี้ฟ้าสีแดงหั่นแลบ	1/2	เม็ด
ข้าวสาร, น้ำเปล่า		

ส่วนผสม (3-4 ที่)

	1.0 ลิตร	1.8 ลิตร	
ไข่ไก่หั่นสุก่า 4 ส่วน	4	4	ฟอง
เต้าหู้หั่นหั่นชิ้นสีเหลืองผึ้งผ้า	20	20	ชิ้น
แตงกวาหั่นชิ้นตามช่วง	2	2	ถูก
มะเขือเทศหั่นชิ้นตามช่วง	2	2	ถูก
กะหล่ำปลีหั่นชิ้น	35	70	กรัม
แครอทหั่นแท่ง	25	50	กรัม
มันผั่งปอกเปลือกหั่นชิ้น	50	100	กรัม
ผักบุ้งไทยหั่นท่อน	50	100	กรัม
ถั่วฝักยาวหั่นท่อน 1 นิ้ว	25	50	กรัม
ถั่วงอก	25	50	กรัม
ข้าวสาร, น้ำเปล่า			

ผู้มีสุขภาพดีควรกินอาหาร

ส่วนผสมซอสถั่ว

พริกชี้ฟ้าแห้งแกะเมล็ดออกแขวน้ำหนอนนึ่ม	1/3	ถ้วยดาว
หอมแดงซอย	3	ช้อนโต๊ะ
กระเทียมซอย	2	ช้อนโต๊ะ
เกลือป่นหยาบ (1)	1	ช้อนชา
กะปิ	1	ช้อนชา
ถั่วถักสิ่งคั่วด้วยเทียน	3/4	ถ้วยดาว
น้ำขุ่นไก่	2	ถ้วย
เกลือป่นหยาบ (2)	1 1/2 - 2	ช้อนชา
น้ำมะขามเปียกความเข้มข้นปานกลาง	2	ช้อนโต๊ะ
น้ำมันงา	1	ช้อนโต๊ะ
น้ำตาลบืน	4	ช้อนโต๊ะ
ชีวิชรา	1 1/2	ช้อนโต๊ะ
น้ำมันพืช	2	ช้อนโต๊ะ

ไข่ตุ๋นกุ้ง



วิธีทำ

1. ตอกไข่ไก่ใส่ภาชนะ ตีพอแตก ใส่เกลือป่น ซีอิ๊วขาว กุ้งสด ตีให้เข้ากัน
2. ค่อนข้างเติมน้ำซุปไปเล็กน้อย แล้วตักต้มสุก ปิดด้วยแผ่นอะลูมิเนียมฟอยล์
3. ใส่ข้าว* และเติมน้ำเปล่าตามระดับของหม้อหุงข้าว วางภาชนะนึ่ง เรียงด้วยถ้วยไข่ตุ๋นใส่ลงไป ปิดฝาหม้อ กดปุ่มรายการ [Menu] เลือกรายการหุงตามชนิดของข้าว
4. กดปุ่มหุงพร้อมนึ่ง [Double Cook] เมื่อมีเสียง警報 ปิดฝาหม้อ ยกลง
5. ตักแต่งหน้าไข่ตุ๋นด้วยกุ้งลวก เท็ดหوم ตันหอม และผักชี จัดเลิร์ฟ

ส่วนผสม (3-4 ที่)

	1.0 ลิตร	1.8 ลิตร	
กุ้งสดหั่นชิ้นตามหัวง	2	2	ช้อนโต๊ะ
กุ้งลวกสำหรับตกแต่ง	3	3	ตัว
ไข่ไก่เบอร์ 2	2	3	ฟอง
น้ำซุปไปร์	1/2	3/4	ถ้วยตวง
ซีอิ๊วขาว	1	1 1/2	ช้อนชา
เกลือป่นหมาย	1/4	1/4	ช้อนชา
ตันหอมซอย	2	2	ช้อนโต๊ะ
ผักชี	3	3	ช่อ
เกลือหอมสดลวกสำหรับตกแต่ง	2	2	ช้อน
ข้าวสาร, น้ำเปล่า			

ปลาบ่อบต้มเค็ม



วิธีทำ

1. ล้างปลาบ่อให้สะอาด พอกไว้ให้สะเด็ดน้ำ
2. ผสมน้ำมันพืช น้ำผึ้ง น้ำปลา เกลือป่น ซีอิ๊วคำหวาน และพริกไทยดำบด คนให้เข้ากัน
3. ใส่กระเทียม หอมแดง พริกชี้ฟู ตันหอม ชิง และปลาบ่อ คลุกเคล้าให้เข้ากัน ตักใส่ถ้วยต้มเบลล์คูกิ
4. ใส่ข้าว* และเติมน้ำเปล่าตามระดับของหม้อหุงข้าว วางภาชนะนึ่ง ตามด้วยภาชนะเบลล์คูกิที่ใส่อาหารไว้ ปิดฝาหม้อ กดปุ่มรายการ [Menu]
- เลือกรายการหุงตามชนิดของข้าว
5. กดปุ่มหุงพร้อมนึ่ง [Double Cook] เมื่อมีเสียง警報 ปิดฝาหม้อ ยกอาหารออกจากหม้อ คนให้เข้ากัน
6. จัดใส่จาน ตักแต่งด้วยผักชี จัดเลิร์ฟร้อนๆ

ส่วนผสม (3-4 ที่)

ปลาบ่อหั่นหัว	350	กรัม
หอมแดงขนาดกลางหั่นหัว	4	หัว
กระเทียมหั่นหมาย	2	ช้อนโต๊ะ
พริกชี้ฟูบบบด	2	เม็ด
ชิงช่าย	2	ช้อนโต๊ะ
น้ำผึ้ง	4	ช้อนโต๊ะ
น้ำปลา	1	ช้อนโต๊ะ
เกลือป่นหมาย	1/2	ช้อนชา
ซีอิ๊วคำหวาน	1	ช้อนชา
พริกไทยดำบด	1/2	ช้อนชา
น้ำมันพืช	2	ช้อนโต๊ะ
ตันหอมหั่นห่อน 1 น้ำ	1	ตัน
ผักชี	1	ช่อ
ข้าวสาร, น้ำเปล่า		

พัตเปียวนหัวนก



ส่วนผสม (3-4 ที่)

เนื้อออกไก่	250	กรัม
น้ำพริกแกงเขียวหวาน	2 1/2	ช้อนโต๊ะ
น้ำมันพืช	1	ช้อนโต๊ะ
หัวกะทิ	1/3	ถ้วยตวง
มะเขือพวง	1	ช้อนโต๊ะ
มะเขือเบร์รี่หันซึ้ง	90	กรัม
ใบมะกรูดจีก	2	ใบ
ใบโภระพา	1/4	ถ้วยตวง
พริกชี้ฟ้าสีเขียว สีแดง สีเหลือง หันแผลบ	1/4	ถ้วยตวง
น้ำปลา	1 1/2	ช้อนโต๊ะ
น้ำตาลปีน	1	ช้อนชา
ข้าวสาร, น้ำเปล่า		

วิธีทำ

1. ล้างอกไก่ให้สะอาด หันชั้นหนาประมาณ 1/2 เซนติเมตร
2. ผสมน้ำมันพืช น้ำพริกแกงเขียวหวาน หัวกะทิ ปูງรสด้วยน้ำปลา น้ำตาลปีน คนให้เข้ากัน
3. ใส่อกไก่ลงในส่วนผสมข้อ 2 คลุกเคล้าให้เข้ากัน ใส่มะเขือเบร์รี่หันซึ้ง มะเขือพวง พริกชี้ฟ้า ใบมะกรูด และใบโภระพา คลุกเคล้าให้เข้ากันอีกครั้ง ตักใส่ภาชนะด้วยเบล็คกี้
4. ใส่ข้าว* และเติมน้ำเปล่าตามระดับของหม้อหุงข้าว วางภาชนะนี้ ตามด้วยภาชนะด้วยเบล็คกี้ ที่ใส่อาหารไว้ ปิดฝาหม้อ กดปุ่มรายการ [Menu] เลือกรายการหุงตามนิยมของข้าว
5. กดปุ่มหุงพร้อมนึ่ง [Double Cook] เมื่อมีเสียง警報ดัง เปิดฝาหม้อ ยกอาหารออกจากหม้อ คนให้เข้ากันอีกครั้ง จัดเรียงพร้อมเสิร์ฟ

หมายเหตุ : - การใช้น้ำพริกสำเร็จรูป ควรระวังความเผ็ดก่อนปรุงรสด้วยน้ำปลา
- ควรดูเวลาเหมาะสมในการหุง จะทำให้มะเขือสุกหัวกัน

พัตพักรวมมิตร



ส่วนผสม (2-3 ที่)

บรรโคลเคลื่ดเบ็นช์อ่า	70	กรัม
เห็ดหอมสดตัดหัวน้ำผึ้งรึ่ง	50	กรัม
ดอกกะหลาดเบ็นช์อ่า	70	กรัม
ข้าวโพเดล่อนตัดท่อน้ำผึ้งรึ่ง	35	กรัม
หน่อเมืองรังตัดท่อน 1 1/2 นิ้ว	25	กรัม
แครอทหั่นตามช่วง	35	กรัม
ถั่วหวาน	20	กรัม
ซอสเห็ดหอม	3	ช้อนโต๊ะ
ชีวิวข้าว	2	ช้อนชา
น้ำตาลทราย	1 1/2	ช้อนชา
น้ำขุ่นไก่	2	ช้อนโต๊ะ
แป้งมันสำปะหลัง	1 1/2	ช้อนชา
กระเทียมลับหยาบ	1	ช้อนโต๊ะ
น้ำมันพืช	1	ช้อนโต๊ะ
ข้าวสาร, น้ำเปล่า		

วิธีทำ

1. ผสมซอสเห็ดหอม ชีวิวข้าว น้ำตาลทราย น้ำขุ่นไก่ แป้งมันสำปะหลัง น้ำมันพืชและกระเทียม คนให้เข้ากัน
2. ใส่ผักทุกชนิดลงในส่วนผสมข้อ 1 คลุกเคล้าให้เข้ากัน ตักใส่ภาชนะด้วยเบล็คกี้
3. ใส่ข้าว* และเติมน้ำเปล่าตามระดับของหม้อหุงข้าว วางภาชนะนี้ ตามด้วยภาชนะด้วยเบล็คกี้ที่ใส่อาหารไว้ ปิดฝาหม้อ กดปุ่มรายการ [Menu] เลือกรายการหุงตามนิยมของข้าว
4. กดปุ่มหุงพร้อมนึ่ง [Double Cook] เมื่อมีเสียง警報ดัง เปิดฝาหม้อ ยกอาหารออกจากหม้อ คนให้เข้ากันอีกครั้ง จัดเรียงพร้อมเสิร์ฟ
6. จัดใส่ภาชนะ จัดเรียง

คลิ๊กตอนทำอาหาร

ข้อมูลจำเพาะ

ชื่อรุ่น		RZ-D10WF	RZ-D18WF
ความจุ		0.18 ~ 1.0 L	0.36 ~ 1.8 L
แรงดันไฟฟ้า		220 V	
ความถี่		50 Hz	
กำลังไฟฟ้า	ทุก	800 W	1000 W
	อุ่น	33 Wh*	40 Wh*
ความยาวสายไฟ		1.2 m	
ขนาด (โดยประมาณ)	ความกว้าง	26 cm	30 cm
	ความสูง	34 cm	38 cm
	ความลึก	23 cm	27 cm
น้ำหนัก (โดยประมาณ)		3.8 kg	4.6 kg
ระบบความปลอดภัย (เซอร์มอลพิวเตอร์)		152 °C	

- * อัตราการใช้ไฟเฉลี่ยต่อหนึ่งชั่วโมงเมื่อรักษาความร้อนในอุณหภูมิห้องที่ 25 องศาเซลเซียส
- อัตราการใช้ไฟเมื่อปิดเครื่องต่อชั่วโมงอยู่ที่ประมาณ 1 วัตต์

จัดจำหน่ายโดย บริษัท อาร์เชลิก อิคเตช โรม แอพเพลย์แอนด์ เซลล์ (ประเทศไทย) จำกัด
เลขที่ 333, 333/1-8 หมู่ 13 ถนนบางนา-ตราด กม. 7 ตำบลบางแก้ว อําเภอบางพลี จังหวัดสมุทรปราการ 10540
โทรศัพท์ 0-2335-5455 โทรสาร 0-2316-1126, 0-2316-1127
Website : (Thai) <https://www.hitachi-homeappliances.com/th-th/>
(Eng) <https://www.hitachi-homeappliances.com/th-eng/>
E-mail : service.hahst@arcelik-hitachi.com
LINE : @AH_THCARE
ราคาแนะนำขายส่ง รวมภาษีมูลค่าเพิ่ม: รุ่น RZ-D10WF ราคา 5,090.00 บาท / RZ-D18WF ราคา 5,390.00 บาท

3RPL116042 2021-07 (AP-AHTH) R0

HITACHI



INSTRUCTION MANUAL

MODEL : RZ-D10WF / RZ-D18WF

HOUSEHOLD



Pineapple Rice



Strawberry Butter Cake

Before Using

Important Safeguards	2
Parts Identification.....	4

Before Cooking Rice

Hints and Tips for Tasty Rice	5
Preparation for Cooking.....	6

How to Cook Rice

How to Cook Rice (White rice, Jasmine rice, Japanese Rice, Brown rice, Mixed grain, Porridge (Thick, Thin), Sticky rice/Mixed rice	7
How to Use Auto Recipe (40 Cooking Menus).....	8
How to Warm Rice	9
How to Double Cook Program	10
How to Bake a Cake	11
How to Slow Cook	12
How to Use Timer	13
How to Steam manually	14
Clean and Care	15
Problems and Solutions.....	16

Cooking Book (For Double Cook Program)

Steamed Prawns with Soy Sauce	17
Steamed Chicken Shanghai Style	17
Steamed Blue Crab with Chili.....	18
Steamed Snow Fish with Soy Sauce	18
Steamed Tofu in Brown Sauce	19
Gado Gado.....	19
Steamed Eggs with Shrimps	20
Braised Snakehead Fish with Soy Sauce	20
Chicken with Green Curry Paste	21
Mixed Vegetables with Mushroom Sauce.....	21

Specifications

Specifications	22
----------------------	----

- Thank you for purchasing HITACHI Electric Rice Cooker
- Please read this instruction manual before use for the proper usage of this product.
Please keep this instruction manual for future reference.

Important Safeguards

This product is for household use only. Do not use for industrial purpose.

 WARNING	Indicate a potential hazard that could result in death or serious injury.
 CAUTION	Indicate a potential hazard that may result in minor or moderate injury or damage to the appliance or property.

Symbol

The following symbols categorize and explain the level of hazard and damage caused when the precaution are disregarded. To fully benefit from this appliance, read carefully these instructions before using the appliance. Failure to do so could result in personal injury to you or damage to the appliance or property.

 WARNING	
Risk of burn injury with jumping out ingredients, blowing out hot water or by suddenly opened lid. To surely close the lid, push the center front of the lid until the "click" sound is made. Do not use this appliance for purposes other than the rice cooking and cooking menu described in Instruction Manual and Cooking Book.	 Do not remove or change any parts of this appliance. Service such as repairing should be performed only by an authorized service representative. It may cause fire, electric shock or burn hazards. In case of service, contact the store where you purchased or customer service department of Hitachi company.  <small>Do not disassemble</small>
Do not attempt to use pin, cord, wire or any other metal particles. It may cause electric shock or injury hazards due to malfunction.	 Use this product with a AC plug rated 5 A or higher alone. Do not use with another plug. When used with other appliances, abnormally heated branching part may cause fire hazards. 
Always keep cooker out of reach of children. It may cause electric shock, burn or injury hazards.	 Always keep the AC plug clean. It may cause fire. 
Do not operate any appliance with a damage cord or plug. It may cause electric shock, short-circuit or fire hazards.	 Make sure the plug fits fully to the socket. It may cause electric shock, short-circuit, smoke or fire hazards. 
Do not attempt to damage a cord in any manner and cord should not be attached near heating source. Damaged cord may cause electric shock or fire hazards.	 Use the product with 220 voltages AC outlet only. It may cause electric shock or fire hazards. 
Do not open the lid while cooking. It may cause burn hazards.	 Avoid immersing the main body in water or putting water in any part of the body. It may cause electric shock or short-circuit hazards.  <small>Avoid water</small>
This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.	 Avoid using wet hands to plug in or unplug. It may cause electrocution.  <small>No wet hands</small>
	Do not touch the steam vent while using. It may cause burn hazards. Keep cooker out of reach of children.  <small>Do not touch</small>

Symbols



This symbol indicates cautions (including dangers or warnings). Concrete descriptions are inside of or next to the mark.



This symbol indicates "prohibition". Concrete descriptions are inside of or next to the mark.




This symbol indicates "compelling". Concrete descriptions are inside of or next to the mark.

CAUTION		
Never use near water or fire. It may cause electric shock or electric leakage.		Unplug from the socket when not in use. It may cause electric shock, electric leakage, burn or injury due to degraded insulating. Unplug
Do not place the cooker on unstable surface or flammable surface such as a carpet or tablecloth. It may cause fire.		Remove the plug from the plug socket by pulling on the plug itself, rather than on the cord. It may cause electric shock, short-circuit, burn hazards.
Use only the dedicated inner pot. It may cause heating or malfunction.		Holding the plug while removing the cord. Pulling the cord can cause skin injury.
Do not touch lid release button when moving the cooker. Opening lid may cause injury or burn hazards.		Maintenance should be done after the cooker cooled down. Touching hot part may cause burn hazards.
Do not place the cooker close to house wall or any other furniture. Do not place the cooker inside kitchen storage cabinet because it may cause accumulated steam. Steam or heat may damage such as discoloration or deformation of wall or furniture.		The appliance normally cleaned after use. Do not touch hot parts such as inner pot or steam vent while using or cooking. It may cause burn hazards. Do not touch

ATTENTION	
<ul style="list-style-type: none"> Do not place a damp cloth on the cooker. It may cause discoloration, deformation or malfunction. 	<ul style="list-style-type: none"> Eliminate any foreign object at the bottom of inner pot, or on heating plate or temperature sensor. It may cause malfunction or improper cooking.
<ul style="list-style-type: none"> Do not stand the handle or move the cooker while cooking. Steam may cause burn hazards. 	
<ul style="list-style-type: none"> Avoid direct light or oil. It may cause discoloration, deformation. 	<ul style="list-style-type: none"> Do not put the inner pot in contact with fire or use it in a microwave oven. It may damage coated surface.


Parts Identification

Parts identification for rice cooker



Operation Area

Operation Buttons



Remark Cook button has convex marks for vision impaired people.

Hints and Tips for Tasty Rice

Hints and tips for tasty rice

Before Using

Hints and tips for tasty rice



Measure rice correctly

- Please use the attached measuring cup to measure rice.
- Measuring rice bins may measure differently from the measuring cup in some cases.

Clean rice quickly and adequately

- Rice absorbs the first water quickly. Drain the first rinse water immediately so that the rice doesn't smell like rice-bran.
- After cleaning, rinse the rice until water becomes clear.

Stir rice after cooking

- Stir the rice at the bottom of inner pot without pressuring it. This will evaporate extra water and make it tasty.
- You should stir rice even if you want keep it warm after cooked.

Warming up the rice with good taste



Avoid the following in order to warm up the rice with good taste

- Warm the cooked rice over 12 hours
- Re-warm cold rice again or add rice
- Warm up rice with a rice scoop inside
- Warm up other rice than rice cook (including sticky rice, brown rice, porridge (thick, thin), Mixed rice))
- Warm up the cooked rice without cleaning well

Small amount of rice

- When only small amount of rice is left, pile it at the center of inner pot. (This will prevent the rice from being dry or wet)

Note

- When you keep rice cook warm over 12 hours, or for other kinds of rice, you can keep the rice tasty by wrapping it with plastic wrap and warm it with microwave oven every time.
- Stirring the rice occasionally during keeping warm can keep it tasty.
- When warming the rice cooked by other appliances, push Warm button to warm the inner pot before putting the rice in.

Knowledge for Rice

Water amount and different kinds of rice

- Fill water to suit each kind of rice and the way you like to cook.

KIND OF RICE	WATER LEVEL	MENU
Jasmine rice	According to the scale of Jasmine rice	Jasmine rice
Japanese rice	According to the scale of Japanese rice	Japanese rice
Tahaeng rice Saohai rice Chaowang rice	According to the scale of White rice	White rice
Mixed rice	According to Mixed Grain Table	Mixed Grain

- Rapid [Rapid ECO] is the menu to cook less than 5 cups of rice for RZ-D18WF in shorter time, within 30 minutes and less than 4 cups of rice for RZ-D10WF. Heating and steaming time is set shorter than regular cooking time; the rice may be slightly harder or less tasty. We recommend using Cook Program unless you are in a hurry.

Why cooked rice is burned?

Ripen rice should be pour water off for good scent and taste. If you prefer not to have burn, clean the rice very well so that it does not have any rice-bran left on the surface. White rice and other kinds of rice (not fragrant (jasmine) rice) tend to have burnt part more often.

Mixed Grain






Type	Mixed ratio	Water level	Menu	Maximum amount of cooking	
				1.0 L	1.8 L
Jasmine rice (Fragrant)	: Sticky rice	3 : 1	Jasmine rice (Fragrant)	Mixed Grain	5 cups
	: Red rice	3 : 1	Brown rice	Mixed Grain	4 cups
	: Brown jasmine rice	1 : 1	Brown rice	Mixed Grain	4 cups
Brown jasmine rice	: Sticky rice	3 : 1	Jasmine rice (Fragrant)	Mixed Grain	5 cups
	: Khao Tah Haeng	1 : 1	Brown rice	Mixed Grain	4 cups

Type of Mixed rice Jasmine rice (Fragrant) : Sticky rice Mixed ratio 3 : 1 mean Jasmine rice (Fragrant) 3 cups : Sticky rice 1 cup

Note After cooking Jasmine rice (Fragrant) : Brown rice and Brown rice : Khao Tah Haeng, you should warm for 10-15 minutes. It will make soft rice and good taste.

Preparation for Cooking

Example : When cooking 3 cups of rice in Rice cooker menu

1 Measure rice with the attached measuring cup <ul style="list-style-type: none"> One exact cup measures approximately 180 ml 																															
2 Clean rice <ul style="list-style-type: none"> ① Use plenty of water to stir rice and drain it immediately. ② Repeat the procedure "Clean ⇔ Rinse" until the water become clear. 	<p>Note</p> <ul style="list-style-type: none"> The inner pot can be used for cleaning rice, but it is recommended to use a separate bowl to clean rice. The fluorine coating of inner pot will be more durable. Rinse it well. (It may burn the rice or add rice-bran odor) Use hands to clean rice, not a dasher. When cooking seasoned steamed rice, it cannot reach up to the maximum rice level. (4 cups for type 1.0 L and 7 cups for type 1.8 L) <p>Cause of Overflow</p> <ul style="list-style-type: none"> Overflowing while cooking rice may cause by washing not clean enough or pour too much water. 																														
3 Pour water to the level suited with type of select rice. <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>WHITE JASMINE JAPANESE</p> <p>ข้าวขาว ข้าวหอมมะลิ ข้าวญี่ปุ่น</p>    </div> <div style="text-align: center;"> <p>JASMINE PORRIDGE</p> <p>ข้าวหอมมะลิ ข้าวต้ม</p>   </div> </div>	<p>Note</p> <ul style="list-style-type: none"> Water levels are only rough standards. You can adjust amount of water as you desire. For sticky rice, the amount of water specified above uses for Kiew Ngoo sticky rice. The amount of water can be adjusted according to kind of rice. Flatten out the surface of rice and adjust the water level. (It may cause uneven cooking) Do not use hot water. (It may cause wet rice) It may cook rice too wet when using too much alkaline water. Do not use Rapid Cook menu for other than white rice and fragrant (jasmine) rice, including sticky rice, porridge, brown rice. <p><Water level></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>SELECT</th> <th>MENU</th> <th>RICE TO BE USED</th> <th>WATER LEVEL</th> </tr> </thead> <tbody> <tr> <td rowspan="5">COOK</td> <td>WHITE RICE</td> <td>Taheang rice, Saohai rice Napee rice, Long-grain rice</td> <td>WHITE</td> </tr> <tr> <td>JASMINE RICE JAPANESE RICE</td> <td>Jasmine rice JAPANESE RICE</td> <td>JASMINE JAPANESE RICE</td> </tr> <tr> <td>STICKY RICE</td> <td>Glutinous rice</td> <td>STICKY</td> </tr> <tr> <td>BROWN RICE</td> <td>Brown rice</td> <td>BROWN</td> </tr> <tr> <td>PORRIDGE</td> <td>Taheang rice, Saohai rice Napee rice, Long-grain rice, Jasmine rice (Fragrant)</td> <td>PORRIDGE (Thick, Thin)</td> </tr> <tr> <td>Mixed Grain</td> <td>See detail in page 5</td> <td>See detail in page 5</td> </tr> <tr> <td rowspan="3">Rapid eco</td> <td>WHITE RICE</td> <td>Taheang rice, Saohai rice Napee rice, Long-grain rice,</td> <td>WHITE</td> </tr> <tr> <td>JASMINE RICE JAPANESE RICE</td> <td>Jasmine rice (Fragrant) JAPANESE RICE</td> <td>JASMINE JAPANESE RICE</td> </tr> </tbody> </table>	SELECT	MENU	RICE TO BE USED	WATER LEVEL	COOK	WHITE RICE	Taheang rice, Saohai rice Napee rice, Long-grain rice	WHITE	JASMINE RICE JAPANESE RICE	Jasmine rice JAPANESE RICE	JASMINE JAPANESE RICE	STICKY RICE	Glutinous rice	STICKY	BROWN RICE	Brown rice	BROWN	PORRIDGE	Taheang rice, Saohai rice Napee rice, Long-grain rice, Jasmine rice (Fragrant)	PORRIDGE (Thick, Thin)	Mixed Grain	See detail in page 5	See detail in page 5	Rapid eco	WHITE RICE	Taheang rice, Saohai rice Napee rice, Long-grain rice,	WHITE	JASMINE RICE JAPANESE RICE	Jasmine rice (Fragrant) JAPANESE RICE	JASMINE JAPANESE RICE
SELECT	MENU	RICE TO BE USED	WATER LEVEL																												
COOK	WHITE RICE	Taheang rice, Saohai rice Napee rice, Long-grain rice	WHITE																												
	JASMINE RICE JAPANESE RICE	Jasmine rice JAPANESE RICE	JASMINE JAPANESE RICE																												
	STICKY RICE	Glutinous rice	STICKY																												
	BROWN RICE	Brown rice	BROWN																												
	PORRIDGE	Taheang rice, Saohai rice Napee rice, Long-grain rice, Jasmine rice (Fragrant)	PORRIDGE (Thick, Thin)																												
Mixed Grain	See detail in page 5	See detail in page 5																													
Rapid eco	WHITE RICE	Taheang rice, Saohai rice Napee rice, Long-grain rice,	WHITE																												
	JASMINE RICE JAPANESE RICE	Jasmine rice (Fragrant) JAPANESE RICE	JASMINE JAPANESE RICE																												
	4 Place the inner pot into the body 	<p>Note</p> <ul style="list-style-type: none"> Dry the inside and the bottom of inner pot and wipe any foreign object. Make sure that the pot has direct contact with the heating plate. Keep turning it slightly until it fits. 																													
5 Close the lid and plug in the cord. 	<p>Note</p> <ul style="list-style-type: none"> Make sure that the inner lid and steam cap are attached. Close the lid slowly until you hear clicking sound. 																														

How to Cook Rice
▼
See P.7

How to Use Auto Recipe
▼
See P.8

How to Warm Rice
▼
See P.9

How to Double Cook
▼
See P.10

How to bake a cake
▼
See P.11

How to slow cook
▼
See P.12

How to Set Timer
▼
See P.13

How to steam Manually
▼
See P.14

How to Cook Rice

White rice, Jasmine rice, Japanese rice, Brown rice,
Mixed Grain, Porridge (Thick,Thin), Sticky rice

Cooking time


- * Power supply 220V, Room temperature 25 °C, Water temperature 25 °C.
 - * Cooking time depends on voltage, room temperature, water temperature and water level including type of rice.
- Cooking time (approximately in maximum minute)

White rice	Jasmine rice	Sticky rice	Brown rice	Porridge	Rapid Eco Cook
45~50	40~45	30~55	70~90	60~80	30 RZ-D10WF 4 Cup of rice RZ-D18WF 5 Cup of rice


Note : For Rapid Eco cook program with rice more than 2 cups, cooking time may increase.

1

Push [MENU] button to select the menu.



When plug is in, current menu setting will be displayed.




- Each time [Menu] is pushed, mark will show Jasmine rice/Japanese rice/Brown rice/Mixed rice/Porridge (Thick,Thin)/Sticky rice.
- The cooker always starts initial setting with White rice menu.
- The cooker will not remember the setting when you select White → Jasmine → Brown → Mixed Grain → Slow Cook Slow Cook High → Porridge → Sticky → Steam → Cake. It will be set back to White rice next time.

2

There are 2 cooking method selections as following:

- 2.1 Normal cooking
- Push [Cook] button



- 2.2 Rapid eco cooking
- Push [Rapid eco] button



You will hear melody and it will start cooking.

* (Normal cooking and super rapid cooking have different melodies.)

When [Cook] or [Rapid eco] button is pushed, the time will not be shown. You will hear the melody and it will start cooking. (Normal cooking and rapid eco cooking have different melodies.) At steaming stage, the time left (min.) will be displayed as below and will count down by a minute.

Method Type	Normal cooking	Rapid eco cooking
White rice	10	5
Jasmine rice	15	5
Japanese rice	15	5
Brown rice	10	-
Sticky rice	5	-
Porridge (Thick/Thin)	10	-

Note for White rice cooking

- Each time after plugging, you could select cooking method immediately by pushing [Cook] button for normal cooking and pushing [Rapid] button for super rapid cooking.


3

Stir the rice as soon as it is cooked and you hear the melody.

Keeping warm

- Though it could keep the rice warm over 12 hours. It is not recommended to do so, because it may cause odor and discoloration.
- Warming may cause dew drops accumulation inside of lid, inner lid or inner pot. This prevents the rice from getting dried, it is not the cooker's malfunction.

Warm light will be on and warming system will automatically work. Please enjoy the rice as soon as possible after it is cooked.



- LCD display will show passed warming time from 0 h to 12 h. (When it reaches the 13th hour, it will be displayed same as when cooking is started.)
- If the rice is not stirred properly, it may absorb steam and become too glutinous or hard.
- You may see a slight dimple in the center of cooked rice, or white and soft rice where it contacts the inner pot.


When rice is cooked, it will be automatically switched to warming operation. If you do not want to warm, push ⇒ [Off/Warm] button and unplug.

Before Using

How to cook rice

How to Use Auto Recipe (40 Cooking Menus)



- Time and method of cooking, please refer to Auto Recipe Cook Book.



Warning

- Do not use for other purpose than cooking as specified in the Cook Book.
- Do not open the lid while cooking, if it is necessary, press Off button to stop procedure and open the lid. (Be careful risk of skin burn)


Example,
[Auto Recipe] Menu 3, Set time 91 minutes.




- Each time you press [Auto Recipe], the number of menu will move one by one, starting from 1 to 10 and recirculate to 1 again.





- Timer can be applied to some menu, which you can see in the Cook Book appendix.



- Each time you press [Up] the time will increase by 1 minute or press [Down] the time will decrease by 1 minute.



- Time of cooking depends on each menu. Please see the manual before setting the proper time.




- [Cook] light will be on.



- The melody (warning sound) rings, the cooking is finished. Put the cooked food in other container.

Note: ● Do not warm or keep the cooked food in the pot (fluorine coating on the inner pot may be damaged).



How to Warm Rice

Tip for keeping rice and tasty

- After cooking is finished, the cooker will automatically change it to "Warm". If the warming, generates smell or makes the rice sticky, "Warming" advice is as follows :

Type of rice	Cooking mode	Warming
WHITE	WHITE	<ul style="list-style-type: none">After the cooking is finished, the cooking mode will change to Warm automatically (WARM light is on).The Warm Mode can run 24 hours. Warming for more than 24 hours can cause odor or color changing.
JASMINE JAPANESE	JASMINE JAPANESE	
BROWN	BROWN	
STICKY	STICKY	<ul style="list-style-type: none">Do not Warm. (Warming may affect quality, smell or consistency of the rice).
MIXED	MIXED RICE	
WHITE BROWN	PORRIDGE	<ul style="list-style-type: none">To stop Warming, press [off] (Warm light will be off).

- Warming may accumulate moisture inside the lid, inner lid or inner pot. This prevents the rice from getting dried, it is not classified as the cooker malfunction.

Tip for Warming tasty rice

- Stir rice occasionally while Warming.
- If the rice quantity is low, accumulate the rice in the middle of the pot (to prevent the rice from getting dried or get clumped).
- Use as less time for warming as possible. Do not warm rice more than 24 hours (in case of warming more than 24 hours can cause odor or color changing).
- Do not warm other rice than White rice, Jasmine rice, Japanese rice (Brown, Porridge, Mixed / Sticky).
- Stir rice well before warming. Do not leave rice scoop in the pot while warming and do not reheat the cold rice.
- You can keep the rice tasty by wrapping it with plastic wrapping paper and warm it in microwave oven.



How to cook rice

How to Reheat the rice in Warm mode

- You can warm the rice again if the rice becoming cool.
- It is recommended that the rice level should be lower than level 3 of water level of [WHITE RICE].

1 Stir rice occasionally during warming and keep the surface flat.


- Note:**
- Do not warm the rice many times (it may cause the rice to get dried or even burned).

2 Press while warming.

- [COOK (REHEAT)] light blinks
- New warming mode will start automatically in around 10 minutes.

- When the rice is still hot after cooking or when the rice has been cooled down, the warning sound will beep and you cannot warm the rice again).

3 After the cooking is finished, cooker will change to warm automatically. Warm light will be on.



- To stop warming, press OFF (Warm light will be off)


How to Double Cook Program

1

Prepare the rice and food to be the steam.


2

Place the inner pot into this appliance and put the food to be steamed in the Double Cook basket.




3

Close the lid and put the plug in the wall socket.



4

Push on [Menu] button to select [White Rice] or [Jasmine Rice]



■ Preparation for cooking ⇒ page 6

■ Preparation for steaming food ⇒ page 17-21


■ Amount of rice for Double Cook Program

2 cups of rice for type 1.0 L

3 cups of rice for type 1.8 L

■ Dry the inside and the bottom of inner pot and wipe any foreign objects.


■ Make sure that the inner pot contact directly with the heating plate. Keep moving slightly until it fits.



■ Each time the plug is in, the mark will show ▶ White rice

■ Make sure that the inner lid and steam cap are attached.



■ Close the lid slowly until you hear clicking sound.



5


Push [Double Cook] button

Melody is played when the cooking is started.
(Type of melody differs from that of
[Normal Cooking] and [Double Cooking]).



6

When the [Double Cook] mode is completed.
[Double Cook] button is turned off and
[Keep-warm] light will be turned on.




- * Open the lid and take out the steam basket
- * Stir the rice as soon as it is cooked.

■ [Keep-warm] light will be turned on and Keep-warm mode automatically starts.


■ Please enjoy tasting the freshly cooked rice.

■ How to use [Keep-warm] mode ⇒ page 7



When the rice is cooked, [Keep-warm] mode starts automatically. If you do not want to use [Keep-warm] mode, please put button and unplug the power cord.



How to Bake a Cake

- 1** Prepare the ingredients for a cake, the amount depends on size of the cooker which indicated in cooking book page 26
- 2** Spread butter around the inside and the bottom of the inner pot to prevent the cake to be sticked.
- 3** Pour the ingredients into the inner pot.
- 4** Place the inner pot into the cooker.
 - Dry the inside and the bottom of inner pot and wipe any foreign objects.
 - Make sure that the inner pot contact directly with the heating plate. Keep moving slightly until it fits.
- 5** Close the lid and plug in the cord.
- 6** Push [Menu] button to select “Cake”
 




Each time  is pushed ▶ mark will show the menu and will be shifted one menu at a time White rice → Jasmine rice/Japanese rice → Brown rice → Mixed Grain → Slow Cook →Slow Cook High → Porridge rice →Sticky rice →Steam →Cake


- 7** Push [Down/Up] button to set the time for “Cake”
 

Each time you push [Up] button, time will increase 5 min. or each time you put [Down] time will decrease 5 min. For the example, timer is set to 40 min. for cake.





- 8** Push [Cook] button.
 
 - You will hear melody and cooking light will be on. Then it will start baking cake with the setting time.
 - LCD will show time left which decrease by one minute.
 - During baking, do not open the lid, the cake will be uncooked.

Note

 - For baking duration: Refer to the attached Cooking Book.
- 9** When the cake is cooked, you will hear melody. Cooking light will be off, Warm light will be on instead. Push  button to cancel cooking operation. Then open the lid immediately.
 
- 10** Unplug the cord and keep it well.
 
- 11** Lift up the inner pot from the cooker and left until it is cooled down, around 3-5 min. Then put the pot upside down on a tray or any prepared vessel.
 - To remove a cake from the inner pot, you should wear heat-protection gloves or use a piece of cloth to carry the inner pot.
- 12** Decorate the cake as your desire.

How to cook rice

How to Slow Cook

- 1** Prepare the ingredients for slow cooking, the amount depends on size of the cooker which some menus are described in cooking book page
- 2** Pour the ingredients into the inner pot.
- 3** Place the inner pot into the cooker.
- Dry the inside and the bottom of inner pot and wipe any foreign objects.
 - Make sure that the inner pot contact directly with the heating plate. Keep moving slightly until it fits.
- 4** Close the lid and plug in the cord.
- Make sure that the steam cap are attached.
 - Close the lid slowly until you hear clicking sound.
- 5** Push [Menu] button to select [Slow Cook].
- 
- 
- 6** Push [Down/Up] button to set the time for slow cooking.
- 
- 
- Each time you push [Up] button, time will increase 30 min. or each time you push [Down] time will decrease 30 min. For example, timer is set to 2 hours 30 min for slow cooking
- Note**
- For Slow cook duration: Refer to the attached Cooking Book.
- 7** Push [Cook] button.
- 
- You will hear melody and cooking light will be on. Then it will start slow cooking with the setting time.
 - LCD will show time left which decrease by one minute.
- 8** Unplug the cord.
- After slow cooking is finished, do not open the lid immediately. Please wait for 2-3 minutes.
 - After using the cooker, always push [Off/Warm] button and unplug for safety.

How to Use Timer

When you set the time to finish (Programmed Cooking)

You can program the time within the maximum 12 hour 30 min.



Note

- Programmed Cooking can be used for White rice, Jasmine rice, Brown rice, Mixed Grain rice, Porridge and Sticky rice.
- Please do not use Programmed Cooking for seasoned steamed rice or rice mixed with other ingredients, since they may not be properly cooked or not appetizing.

(Example) Current time is 7.00 PM. We want to finish Programmed Cooking for tomorrow at 6.30 AM. Therefore, timer should be set to 11 hours 30 min. according to time difference between time to finish and current time.

1

Push [Down/Up] button according to time difference.




- Select menu
- Each time you push [Down] button, time will decrease 30 min. Or each time you push [Up] button, time will increase 30 min.
For the above example, timer is set to 11 hours 30 min.



- Cook button light and LCD display will blink while timer is setting.

2

Push [Cook] button.



Note

- You could not program cooking unless you push [Cook] button to turn on the cooker.






- Push [Cook] button, timer will start working. Cooking light will be off and there will be buzzer sound.
- LCD will show time left which decrease by one minute.
- When rice is cooked, warm light will be on and there will be buzzer sound to show cooking is finished.

Tips

- Push [Off/Warm/Beep] button to cancel programmed setting.
- Unplugging after setting timer will cancel the setting and timer will return to initial setting.
- Finishing time may slightly different from the set time depending on water temperature, room temperature, voltage or water level.

ການຕັ້ງລາຍການ

How to Steam manually

1 Steaming Other	 <p>Steam basket Water</p> <ul style="list-style-type: none"> Fill water into the inner pot <ul style="list-style-type: none"> : 1.0L at water level 3 cups (Jasmine rice) : 1.8L at water level 4 cups (Jasmine rice) Put the steam basket in the inner pot. Put vegetable or food in the steam basket. How to place the inner pot. (See details page 6) 								
2 Steaming Sticky Rice Preparation of steaming Sticky Rice Measure the sticky rice with supplied measuring cup.	<ul style="list-style-type: none"> Fill with enough water, rinse the rice. Then pour the water immediately. Repeat the process "rinse ⇔ pour" until the water is clear. Soak the rice in the clean water for 1 hour. 								
3 Steaming Sticky Rice	 <p>※ Before cooking, soak the Sticky Rice in water for 1 hour.</p> <ul style="list-style-type: none"> Fill water into the inner pot <ul style="list-style-type: none"> : 1.0L at water level 3 cups (Jasmine rice) : 1.8L at water level 4 cups (Jasmine rice) Place the damp cheesecloth into the steam basket and put the steam basket in the inner pot. Put the soaked rice into the steam basket. Fold the ends of cheesecloth over the rice and close the lid. (If do not use the cheesecloth, cannot cook Sticky Rice well.) 								
4 Plug into the socket.	 <ul style="list-style-type: none"> Every time you plug in, ▶ mark will be at White rice position. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Bread/Cake Steam Mixed/Sticky Porridge</td> <td>▶</td> <td>White (Jasmine/ Brown Mixed Grain)</td> </tr> <tr> <td colspan="2">Slow Cook</td> <td></td> </tr> </table>	Bread/Cake Steam Mixed/Sticky Porridge	▶	White (Jasmine/ Brown Mixed Grain)	Slow Cook				
Bread/Cake Steam Mixed/Sticky Porridge	▶	White (Jasmine/ Brown Mixed Grain)							
Slow Cook									
5 Push [Menu] button to select [Steam].	 <ul style="list-style-type: none"> Each time [Menu] is pushed, ▶ mark will show the menu and will be shifted one menu at a time White rice → Jasmine rice/Japanese rice → Brown rice → Mixed Grain → Slow Cook → Slow Cook High → Porridge (Thick/Thin) → Sticky rice → Steam → Cake "Timer" message will be shown and time setting for slow cooking will be blinked with cook light blinking while setting time. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Bread/Cake Steam Mixed/Sticky Porridge</td> <td>◀</td> <td>Timer H 30 M</td> <td>White (Jasmine/ Brown Mixed Grain)</td> </tr> <tr> <td colspan="2">Slow Cook</td> <td></td> <td></td> </tr> </table>	Bread/Cake Steam Mixed/Sticky Porridge	◀	Timer H 30 M	White (Jasmine/ Brown Mixed Grain)	Slow Cook			
Bread/Cake Steam Mixed/Sticky Porridge	◀	Timer H 30 M	White (Jasmine/ Brown Mixed Grain)						
Slow Cook									
6 Push [Down/Up] button to set the time for steaming.	 <ul style="list-style-type: none"> Each time you push [Up] button, time will increase 1 minute or each time you push [Down] button, time will decrease 1 minute. For the above example, the steaming time is set for 30 minutes. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Bread/Cake Steam Mixed/Sticky Porridge</td> <td>◀</td> <td>Timer H 30 M</td> <td>White (Jasmine/ Brown Mixed Grain)</td> </tr> <tr> <td colspan="2">Slow Cook</td> <td></td> <td></td> </tr> </table>	Bread/Cake Steam Mixed/Sticky Porridge	◀	Timer H 30 M	White (Jasmine/ Brown Mixed Grain)	Slow Cook			
Bread/Cake Steam Mixed/Sticky Porridge	◀	Timer H 30 M	White (Jasmine/ Brown Mixed Grain)						
Slow Cook									
7 Push [Cook] button.	 <ul style="list-style-type: none"> You will hear melody and cooking light will be on. The show time for steaming will stop blinking. Then it will start steaming with the time. At the time of water in inner pot is boiled, setting timer starts. And LCD will show time left which decrease by one minute. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Bread/Cake Steam Mixed/Sticky Porridge</td> <td>◀</td> <td>Timer H 30 M</td> <td>White (Jasmine/ Brown Mixed Grain)</td> </tr> <tr> <td colspan="2">Slow Cook</td> <td></td> <td></td> </tr> </table>	Bread/Cake Steam Mixed/Sticky Porridge	◀	Timer H 30 M	White (Jasmine/ Brown Mixed Grain)	Slow Cook			
Bread/Cake Steam Mixed/Sticky Porridge	◀	Timer H 30 M	White (Jasmine/ Brown Mixed Grain)						
Slow Cook									
8 Unplug from the socket.	 <ul style="list-style-type: none"> After steaming is finished, do not open the lid immediately. Please wait for 2-3 minutes. After using the cooker, always push [Off/Warm] button and unplug for safety. 								

Clean and Care

Cleaning method for rice cooker model RZ-D10XF/RZ-D18XF

- Make sure that you unplug cooker and the body is cold for maintenance.
- Avoid using benzene, thinner, polishing powder or scrub brush to clean the cooker. (It may damage the surface.)

Body/Lid


Wipe with damp cloth.



Rice Scoop/Measuring Cup/ Steam Basket/Double Cook Basket


Wash with soft material such as sponge by using dish soap.

③ Cleaning




How to attach

- ① Insert the claw and lock into the



- ② Press steam cap cover into the steam cap



- ③ Insert steam cap to the lid

Push the center part off steam cap to push in all the way to the bottom




Due drops should be wiped after every usage.

Remove rice or stickiness from the inner lid, since it may cause rice being dried out while warming.

Heating Plate Temperature Sensor

If there is rust on heating plate or temperature sensor, use fine sandpaper (No. 600) to rub it off and then wipe with damp cloth.



Inner Pot

Wash with soft material such as sponge. When it doesn't get cleaned, use mild detergent (Dish detergent)

Note

- It may not cook properly if the inner pot is deformed. To avoid that, handle it with care.
- To avoid damaging fluorine coating
 - Use attached rice scoop
 - Do not wash it with spoons or bowls in
 - Do not use vinegar
 - Do not scrub inside with polishing powder or scrubbing brush
 - Clean rice in another container
- Fluorine coating will be worn by repetitive use, handle it with care

While using inner pot, no-evenly coloring may occur, which will not effect with rice cooking or your health.

Problems and Solutions


Please check the following points before contacting to the repair service.

Problem		Check points/When...														
		Page to refer		Amount of rice water level is wrong	Did not rinse rice	The bottom of inner pot or foreign object are attached to temperature sensor	Rice is stuck to the rim of inner pot or inner lid	I did not clean inner pot or inside of the lid	Forgot to attach steam cap	Select a wrong menu	Open the lid while cooking	I Power failed	Used star-burst connection, - or extension cord	Did not stir rice well	Warmed rice over 12 hours, or warmed other rice than rice cook	Unplug or push off button while cooking
Cooked rice	Is too hard		●		●	●				●	●	●	●	●		
	Is half-cooked		●	●	●	●				●	●	●	●			●
	Is too soft		●		●					●	●	●	●	●		
	Has odor			●				●								
Badly burn				●	●					●		●				
Boiled over			●	●	●	●	●	●	●	●						●
Steam leaks from the place other than steam vent						●										
Warm rice	Has odor			●				●			●		●	●	●	
	Is yellow		●	●	●	●			●				●	●		
	Hardened		●				●		●				●	●	●	
Warming temperature is too low																●
Too much dew drops											●		●			●
Water overflowing while cooking			●	●												
Cannot operate with buttons																
The cooker makes sounds when in use																
It has odor while cooking																
Lid is impossible/hard to close																
<ul style="list-style-type: none"> • After checking all the points above and you still experience problems, please contact the store Where you purchased the product. • If inner pot is deformed or its fluorine coating is damaged, please purchase new one. • If H1~H7 shown on the LCD display, please contact the store where you purchased the product. 																

- After checking all the points above and you still experience problems, please contact the store Where you purchased the product.
- If inner pot is deformed or its fluorine coating is damaged, please purchase new one.
- If H1~H7 shown on the LCD display, please contact the store where you purchased the product.

When a power failure occurs

- ① When a power failure occurs while cooking or warming rice, the Rice Cooker will stop working and the LCD display will go Off. (nothing showing in the display)
- ② When power returns, a flashing “--” mark will inform you that there was a power failure and the Rice Cooker has stopped.
- ③ The “--” mark will disappear if you push the [Off/Warm] button.
- ④ If the rice is not cooked yet, push [Cook/Reheat] button to start cooking again.
- ⑤ If the rice is already cooked and you want to keep the rice warm, push [Off/Warm] button once and warm light will turn on.



Note

- When rice is not cooked well, check the LCD display every time. If “--” mark is flashing, Rice Cooker is functioning normally by signaling a power failure.
- In case of long period of power failure and when the temperature of rice is low, the “--” mark may not appear. Therefore, any time the rice is not cooked well, try cooking again.

Cooking Book (For Double Cook Program)

* Amount of rice for Double Cook Program
2 cups of rice for type 1.0 L and 3 cups of rice for type 1.8L

Steamed Prawns with Soy Sauce



Ingredients [2-3 servings]

3 prawns 120-140 grams each
1 teaspoon finely grounded coriander roots
1 teaspoon finely grounded garlic
1/8 teaspoon grounded pepper
2 teaspoons mushroom sauce
1 tablespoon light soy sauce
1 teaspoon sugar
1 tablespoon sesame oil
Fresh coriander leaves for garnish
Long red chili sliced
Rice
Plain water

Instruction

1. Rinse prawns, cut off the antennas and legs. With a sharp knife cut down the back of the prawns into two pieces.
2. Mix coriander root with garlic, pepper and seasonings.
3. Place prawns in the Double cook basket and pour prepared seasonings over the prawns.
4. Put rice* in the pot, add water up to the marked level. Place steam basket and prawn tray on top.
Close the lid. Press [Menu] to select the type of rice.
5. Press [Double Cook] button. When rice is cooked, alarm will ring. Open the lid and lift the tray out.
Arrange the food in the serving plate, garnish with red chili and coriander leaves. Serve while hot.

Steamed Chicken Shanghai Style



Ingredients [2-3 servings]

2 chicken breast 180 grams each
1 spring onion cut into 1"long
3 bunches coriander leaves
1/2 long red chili, finely sliced lengthwise
1/4 cup spring onion, finely chopped
Japanese cucumber, sliced [or any available cucumber]
Rice, Plain water

Shanghai Sauce Seasoning

1 1/2 tablespoons Shoyu [Japanese Sauce]
2 teaspoons Chinese black vinegar
2 teaspoons sesame oil
2 teaspoons peanut butter
1 teaspoon garlic, finely minced
1/4 teaspoon pepper
1 tablespoon ginger, chopped

Instruction

1. Trim chicken breast and rinse well. Let dry.
2. Mix all seasoning ingredients with chicken breasts. Leave to marinate for 1 hour.
3. Place chicken in the Double cook basket and pour prepared seasonings over the chicken.
4. Put rice* in the pot, add water up to the marked level. Place steam basket and chicken tray on top.
Close the lid. Press [Menu] to select the type of rice.
5. Press [Double Cook] button. When rice is cooked, alarm will ring. Open the lid and lift the chicken tray out. Slice the chicken into pieces.
6. Arrange the cucumbers and place chicken in the serving plate. Pour the sauce from the tray over the chicken, garnish with coriander leaves, spring onion and red chili.

Steamed Blue Crab with Chili



Ingredients [2-3 servings]

1 fresh blue crab [500 grams]
1/3 cup long red chili, sliced for grounding
1 long red chili, seeded and chopped
2 tablespoons shallot, finely sliced
1 tablespoon ginger, finely sliced
1 tablespoon garlic, chopped
1/2 cup onion, chopped
4 tablespoons ketchup
1 tablespoon vegetable oil
3 tablespoons Thai chili paste
1 teaspoon rice vinegar
2 tablespoons chicken stock
5 teaspoons sugar
1 1/2 teaspoons coarse salt
1 teaspoon tapioca starch
1 egg
1 spring onion, cut into 1"long
3 bunches coriander leaves
Rice, Plain water

Instruction

1. Rinse and clean the crab well. Break the shell and cut into pieces. Set aside.
2. Ground the chili with shallots, garlic finely.
3. Mix ketchup with vegetable oil, Thai chili paste, rice vinegar, sugar, coarse salt, tapioca starch, chicken stock, egg, grounded chili, onion, chopped red chili and spring onion. Mix it well.
4. Add crab into the mixture and stir it. Place in the Double cook basket.
5. Put rice* in the pot. Add water up to the marked level. Place steam basket and crab tray on top.
Close the lid. Press [Menu] to select the type of rice.
6. Press [Double Cook] button. When rice is cooked, alarm will ring. Open the lid and lift the crab tray out.
7. Stir the mixture and arrange it in the serving plate. Garnish with coriander leaves and serve while hot.

Remark : - The taste is a bit spicy

Steamed Snow Fish with Soy Sauce



Ingredients [2-3 servings]

2 snow fish 100 g each
30 grams pork belly, finely sliced
1 to 1 1/2 tablespoons light soy sauce
1 teaspoon sesame oil
3 tablespoons ginger, finely sliced
1 spring onion, finely sliced
1/2 long red chili, finely sliced
Rice
Plain water

Instruction

1. Rinse and clean the fish well. Place on a colander to dry.
2. Place snow fish in the Double cook basket, add pork belly, ginger, season with light soy sauce and sesame oil.
3. Put rice* in the pot, add water up to the marked level. Place steam basket and fish tray on top.
Close the lid. Press [Menu] to select the type of rice.
4. Press [Double Cook] button. When rice is cooked, alarm will ring. Open the lid and lift the vegetables tray out.
5. Arrange the fish in the serving plate. Garnish with spring onion and chili. Serve while hot.

Steamed Tofu in Brown Sauce



Ingredients [3-4 servings]

250 grams soft tofu, cut into pieces
1 tablespoon garlic, chopped
6 fresh shitake mushrooms, halved
1 tablespoon vegetable oil
1 tablespoon mushroom sauce
2 teaspoons light soy sauce
1 teaspoon sugar
2 teaspoons sesame oil
1/4 teaspoon pepper
1/2 cup chicken stock
2 teaspoons tapioca starch
2 spring onion, cut into 1" long
1/2 long red chili, diagonal sliced
Rice, Plain water

Instruction

1. Mix vegetable oil with garlic and season with mushroom sauce, light soy sauce, sugar, sesame oil, pepper, chicken stock and tapioca starch. Stir to combine.
2. Add shitake mushroom, tofu and onion spring and stir to combine. Transfer mixture to the Double cook basket.
3. Put rice* in the pot, add water up to the marked level. Place steam basket and tofu tray on top.
Close the lid, Press [Menu] button to select the type of rice.
4. Press [Double Cook] button. When rice is cooked, alarm will ring. Open the lid and the tofu tray out.
5. Arrange tofu in the serving plate. Garnish with chili. Serve while hot.

Gado Gado



Ingredients [3-4 servings]

1.0L 1.8L
4 4 boiled eggs, quartered
20 20 pieces fried tofu, cut into rectangles
2 2 cucumbers, sliced
2 2 tomatoes, sliced crosswise
35 70 grams cabbage, cut into pieces
25 50 grams carrot, cut into sticks
50 100 grams potatoes, peeled and cut into pieces
50 100 grams Thai water spinach, cut into pieces
25 50 grams string bean, cut into 1" long
25 50 grams bean sprouts

Peanut sauce

Rice, Plain water

COOKING BOOK

Peanut sauce ingredients

1/3 cup dried long red chili, seeded and soaked
3 tablespoons shallot, finely sliced
2 tablespoons garlic, finely sliced
1 teaspoon coarse salt [1]
1 teaspoon kapi [Thai chili paste]
3/4 cup roasted peanut, grounded
2 cup chicken stock
1 1/2 - 2 teaspoons coarse salt [2]
2 tablespoons tamarind paste
1 tablespoon lime juice
4 tablespoons palm sugar
1 1/2 tablespoons sweet soy sauce
2 tablespoons vegetable oil

Instruction (For Gado Gado)

1. Put cabbage, carrot, potatoes, water spinach, string beans and bean sprouts in the Double cook basket.
2. Put rice* in the pot, add water up to the marked level.
Place steam basket and cabbages tray on top. Close the lid.
Press [Menu] to select the type of rice.
3. Press [Double Cook] button. When rice is cooked, alarm will ring.
Open the lid and lift the cabbages tray out.
4. Arrange steamed and fresh vegetables in the serving plate.
Add tofu and eggs and serve with peanut sauce.

Instruction (For Peanut Sauce)

1. Ground the chili with salt [1] in a mortar and add shallot, garlic and chili paste, continue grinding until the paste is fine.
2. Pour vegetable oil in the pot. Press Rapid eco button. When the pot is hot, add the prepared chili and stir fry for 5 minutes.
3. Add chicken stock and season with salt [2], tamarind paste, lime juice, palm sugar, sweet soy sauce and peanut. Stir to combine.
Close the lid. Frequently check until the sauce thickened. Press stop and transfer the sauce into sauce bowl.

Steamed Eggs with Shrimps



Ingredients [3-4 servings]

1.0L	1.8L	
2	2	tablespoons fresh shrimps, sliced
3	3	boiled fresh shrimps for topping
2	3	eggs
1/2	3/4	cup chicken stock
1	1 1/2	teaspoons light soy sauce
1/4	1/4	teaspoon coarse salt
2	2	tablespoons spring onion, sliced
3	3	bunches coriander leaves
2	2	shitake mushroom, blanched for topping
Rice		
Plain water		

Instruction

1. Break the eggs in a mixing bowl. Beat well. Add salt, light soy sauce and sliced shrimps. Mix well.
2. Gradually pour chicken stock into the mixture while beating. Pour mixture into a serving bowls or the Double cook basket cover with aluminum foil.
3. Put rice* in the pot, add water up to the marked level. Place steam basket and egg bowls on top. Close the lid. Press [Menu] to select the type of rice.
4. Press [Double Cook] button. When rice is cooked, alarm will ring. Open the lid and lift the eggs tray out.
5. Garnish steamed eggs with boiled shrimps, mushroom, spring onion and coriander leaves.

Braised Snakehead Fish with Soy Sauce



Ingredients [3-4 servings]

350 grams	snakehead fish, cut crosswise
4	medium size shallots, sliced
2	tablespoons garlic, chopped
2	bird chili, crushed
2	tablespoons ginger, sliced
4	tablespoons honey
1	tablespoon fish sauce
1/2	teaspoon coarse salt
1	teaspoon sweet soy sauce
1/2	teaspoon black pepper, grounded
2	tablespoon vegetable oil
1	spring onion, cut into 1" long
1	bunch coriander leaves

Instruction

1. Rinse and clean the fish well. Let it dry.
2. Mix vegetable oil with honey, fish sauce, salt, sweet soy sauce and pepper. Mix well.
3. Add garlic, Shallots, bird chili, spring onion, ginger and snakehead fish and stir it well. Transfer mixture to the Double cook basket.
4. Put rice* in the pot, add water up to the marked level. Place steam basket and fish tray on top. Close the lid. Press [Menu] to select the type of rice.
5. Press [Double Cook] button. When rice is cooked, alarm will ring. Open the lid and lift the fish tray out.
6. Arrange the fish in a serving plate and garnish with coriander leaves. Serve while hot.

Chicken with Green Curry Paste



Ingredients [3-4 servings]

250 grams chicken breast
2 1/2 tablespoons green curry paste
1 tablespoon vegetable oil
1/3 cup coconut cream
1 tablespoon pea eggplants
90 grams Thai eggplants, cut into pieces
2 kaffir lime leaves, shredded
1/4 cup sweet basil leaves
1/4 cup long green, red and yellow chilies, diagonally sliced
1 1/2 teaspoons fish sauce
1 teaspoon palm sugar
Rice
Plain water

Instruction

1. Rinse and clean chicken and cut into 1/2 cm long.
2. Mix vegetable oil with green curry paste, coconut cream and season with fish sauce and palm sugar. Stir it well.
3. Mix chicken with the prepared seasonings. Add Thai eggplants, pea eggplant, chilies, kaffir lime leaves and sweet basil leaves. Place mixtures in the Double cook basket.
4. Put rice* in the pot, add water up to the marked level. Place steam basket and chicken tray on top. Close the lid. Press [Menu] to select the type of rice.
5. Press [Double Cook] button. When rice is cooked, alarm will ring. Open the lid and lift the chicken tray out. Arrange in the serving plate. Serve while hot.

Remarks : - When using ready-made curry paste, be cautious before adding fish sauce since fish sauce taste might be already included in the ready-made paste.
- Place eggplants around the edge of inner basket to help thorough cooking.

Mixed Vegetables with Oyster Sauce



Ingredients [2-3 servings]

70 grams broccoli, cut into floral
50 grams shiitake mushroom, halved
70 grams cauliflower, cut into floral
35 grams baby corn, halved
25 grams asparagus, cut into 1 1/2" long
35 grams carrot, sliced
20 grams sweet pea
3 tablespoons mushroom sauce
2 teaspoons light soy sauce
1 1/2 teaspoons sugar
2 tablespoons chicken stock
1 1/2 teaspoons tapioca starch
1 tablespoon garlic, chopped
1 tablespoon vegetable oil
Rice, Plain water

Instruction

1. Mix mushroom sauce with light soy sauce, sugar, chicken stock, tapioca starch, vegetable oil and garlic. Mix well.
2. Add all vegetables and mix it well. Transfer to the Double cook basket.
3. Put rice* in the pot, add water up to the marked level. Place steam basket and vegetables tray on top. Close the lid. Press [Menu] to select the type of rice.
4. Press [Double Cook] button. When rice is cooked, alarm will ring. Open the lid and lift the vegetables tray out.
5. Arrange vegetables in the serving plate and serve.

Specifications

Model		RZ-D10WF	RZ-D18WF
Cooking capacity		0.18 ~ 1.0 L	
Power supply		220 V	
Frequency		50 Hz	
Power consumption	Cooking	800 W	1000 W
	Warming	33 Wh*	40 Wh*
Cord length		1.2 m	
Dimensions (Approximately)	Width	26 cm	30 cm
	Depth	34 cm	38 cm
	Height	23 cm	27 cm
Weight (Approximately)		3.8 kg	4.6 kg
Safety system (Thermal fuse)		152 °C	

* The average power consumption per hour of keep warm at a room temperature of 25°C.

• Power consumption in Off status per hour is approximately 1 W.

Distributed by : Arcelik Hitachi Home Appliances Sales (Thailand) Ltd.

No. 333, 333/1-8 Moo 13 Bangna-Trad (km.7) Road, Bangkaew, Bangplee, Samutprakarn 10540

Tel. 0-2335-5455 Fax 0-2316-1126, 0-2316-1127

Website : (Thai) <https://www.hitachi-homeappliances.com/th-th/>

(Eng) <https://www.hitachi-homeappliances.com/th-eng/>

Email : service.h-aht@arcelik-hitachi.com

LINE : @AH_THCARE

Retail price included VAT : MODEL RZ-D10WF : 5,090 Baht/ RZ-D18WF : 5,390 Baht